

TEXT

A.C. GENERATOR INSTALLATION	9 - 5	EXHAUST MUFFLER REMOVAL	2 - 6
A.C. GENERATOR REMOVAL	9 - 2	EXHAUST MUFFLER	17 - 2
AIR CLEANER	3 - 6	FINAL REDUCTION ASSEMBLY	8 - 5
AIR SCREW ADJUSTMENT	12 -10	FINAL REDUCTION DISASSEMBLY	8 - 2
AUTO BYSTARTER	12 - 5	FINAL REDUCTION GEAR OIL	3 - 9
BATTERY	15 - 4	FINAL REDUCTION INSPECTION	8 - 2
BRAKE CALIPER	13 -11	FLOAT CHAMBER	12 - 7
BRAKE SYSTEM	3 -11	FLOAT LEVEL INSPECTION	12 - 9
BULB REPLACEMENT	16 - 7	FRAME COVERS REMOVAL	2 - 2
CARBURETOR INSTALLATION	12 -10	FRONT BRAKE	13 - 8
CARBURETOR REMOVAL	12 - 4	FRONT FORK	13 -18
CHARGING SYSTEM	15 - 3	FRONT SHOCK ABSORBER	13 -14
CLUTCH/DRIVEN PULLEY	7 -11	FRONT WHEEL	13 - 5
COOLING SYSTEM	3 -10	FUEL LINE/FUEL FILTER	3 - 5
CRANKCASE ASSEMBLY	10 - 6	FUEL UNIT	16 - 2
CRANKCASE SEPARATION	10 - 2	HEADLIGHT AIM	3 -10
CRANKSHAFT INSPECTION	10 - 3	IGNITION SYSTEM	15 - 7
CRANKSHAFT INSTALLATION	10 - 4	IGNITION TIMING	3 - 7
CRANKSHAFT REMOVAL	10 - 2	INSPECTION AND MAINTENANCE	
CYLINDER COMPRESSION	3 - 8	SCHEDULE	3 - 2
CYLINDER HEAD	6 - 2	INSTRUMENT/HEADLIGHT	16 - 8
CYLINDER/PISTON	6 - 6	KICK STARTER	7 - 2
DRIVE BELT	7 - 6	LUBRICATION POINTS	1 -16
DRIVE BELT	3 - 9	LUBRICATION SYSTEM	3 -14
DRIVE PULLEY	7 - 8	NUTS/BOLTS/FASTENERS	3 -13
ENGINE INSTALLATION	5 - 4	OIL METER	16 - 3
ENGINE REMOVAL	5 - 2	OIL PUMP BLEEDING	4 - 4
ENGINE SERIAL NUMBER	1 - 1	OIL PUMP INSPECTION	4 - 2
EXHAUST EMISSION CONTROL SYSTEM	17 - 1	OIL PUMP INSTALLATION	4 - 3
EXHAUST EMISSION RELATED SYSTEM		OIL PUMP REMOVAL	4 - 2
INSPECTION	17 - 3	OIL TANK	4 - 5

TEXT

RADIATOR	11 - 3	STOP SWITCH INSPECTION/HORN	16 - 6
REAR BRAKE DRUM	14 - 5	SUSPENSION	3 -13
REAR BRAKE	14 - 2	SWITCHES	16 - 4
REAR FORK	14 - 3	THERMOSENSOR	11 -12
REAR SHOCK ABSORBER	14 - 7	THERMOSTAT	11 -13
REAR WHEEL	14 - 3	THROTTLE OPERATION	3 - 5
REED VALVE	12 -11	THROTTLE VALVE DISASSEMBLY	12 - 2
SERVICE INFORMATION	11 - 1	THROTTLE VALVE INSTALLATION	12 - 3
SERVICE INFORMATION	14 - 1	TORQUE VALUES	1 -14
SERVICE INFORMATION	10 - 1	TROUBLESHOOTING	11 - 1
SERVICE INFORMATION	12 - 1	TROUBLESHOOTING	14 - 1
SERVICE INFORMATION	13 - 1	TROUBLESHOOTING	10 - 1
SERVICE INFORMATION	15 - 1	TROUBLESHOOTING	12 - 1
SERVICE INFORMATION	16 - 1	TROUBLESHOOTING	13 - 2
SERVICE INFORMATION	6 - 1	TROUBLESHOOTING	15 - 1
SERVICE INFORMATION	7 - 1	TROUBLESHOOTING	16 - 1
SERVICE INFORMATION	8 - 1	TROUBLESHOOTING	6 - 1
SERVICE INFORMATION	9 - 1	TROUBLESHOOTING	7 - 1
SERVICE INFORMATION	2 - 1	TROUBLESHOOTING	8 - 1
SERVICE INFORMATION	3 - 1	TROUBLESHOOTING	1 -24
SERVICE INFORMATION	4 - 1	TROUBLESHOOTING	2 - 1
SERVICE INFORMATION	5 - 1	TROUBLESHOOTING	4 - 1
SERVICE PRECAUTIONS	1 - 4	WATER PUMP	11 - 6
SPARK PLUG	3 - 7	WHEELS/TIRES	3 -13
SPECIAL TOOLS	1 -15	WIRING DIAGRAM	1 -22
SPECIFICATIONS	1 - 2		
STARTER PINION	7 -10		
STARTING SYSTEM	15 -11		
STEERING HANDLEBAR	13 - 3		
STEERING HANDLEBAR	3 -13		
