

## **16. BATTERY/CHARGING SYSTEM**

---

**16**

---


### **BATTERY/CHARGING SYSTEM**

---


CHARGING SYSTEM LAYOUT-----	16-1
SERVICE INFORMATION -----	16-2
TROUBLESHOOTING -----	16-3
BATTERY-----	16-4
CHARGING SYSTEM -----	16-5
A.C. GENERATOR INSPECTION -----	16-5
REGULATOR/RECTIFIER INSPECTION -----	16-6

# 16. BATTERY/CHARGING SYSTEM

## CHARGING SYSTEM LAYOUT



## CHARGING CIRCUIT



# 16. BATTERY/CHARGING SYSTEM

## SERVICE INFORMATION

### GENERAL INSTRUCTIONS

**\***

The battery electrolyte (sulfuric acid) is poisonous and may seriously damage the skin and eyes. Avoid contact with skin, eyes, or clothing. In case of contact, flush with water and get prompt medical attention

- The battery can be charged and discharged repeatedly. If a discharged battery is not used for a long time, its service life will be shortened. Generally, the capacity of a battery will decrease after it is used for 2\_ 3 years. A capacity-decreased battery will resume its voltage after it is recharged but its voltage decreases suddenly and then increases when a load is added.
- When a battery is overcharged, some symptoms can be found. If there is a short circuit inside the battery, no voltage is produced on the battery terminals. If the rectifier won't operate, the voltage will become too high and shorten the battery service life.
- If a battery is not used for a long time, it will discharge by itself and should be recharged every 3 months.
- A new battery filled with electrolyte will generate voltage within a certain time and it should be recharged when the capacity is insufficient. Recharging a new battery will prolong its service life.
- Inspect the charging system according to the sequence specified in the Troubleshooting.
- Do not disconnect and soon reconnect the power of any electrical equipment because the electronic parts in the regulator/rectifier will be damaged. Turn off the ignition switch before operation.
- It is not necessary to check the MF battery electrolyte or fill with distilled water.
- Check the load of the whole charging system.
- Do not quick charge the battery. Quick charging should only be done in an emergency.
- Remove the battery from the motorcycle for charging.
- When replacing the battery, do not use a traditional battery.
- When charging, check the voltage with an electric tester.

### SPECIFICATIONS

Item			Standard
Battery	Capacity		12V10AH
	Voltage (20°C )	Fully charged	13.2V
		Undercharged	12.3V
	Charging current		STD: 1.2 A Quick: 5.0A
	Charging time		STD: 5-10hr Quick:60min
A.C. Generator	Capacity		180W/5000rpm
	Charging coil resistance (20°C )		Yellow_ Yellow   1.6_ 2.5□
	Charging rpm		1300rpm max (14V)
	Charging performance		9A min/5000rpm
Regulator/Rectifier	Limit voltage		14.5±0.5V

### TESTING INSTRUMENTS

Ammeter  
Electric tester: YF-3501  
Tachometer

### TORQUE VALUES

Pulser coil bolt 4.9N-m  
Coil lock bolt 8.8N-m  
Flywheel nut 58.8N-m

## **16. BATTERY/CHARGING SYSTEM**

---

### **SPECIAL TOOLS**

Flywheel holder	E021
Flywheel puller	E003

### **TROUBLESHOOTING**

#### **No power**

- Dead battery
- Disconnected battery cable
- Fuse burned out
- Faulty ignition switch

#### **Low power**

- Weak battery
- Loose battery connection
- Charging system failure
- Faulty regulator/rectifier

#### **Intermittent power**

- Loose battery cable connection
- Loose charging system connection
- Loose connection or short circuit in ignition system

#### **Charging system failure**

- Loose, broken or shorted wire or connector
- Faulty regulator/rectifier
- Faulty A.C. generator

# 16. BATTERY/CHARGING SYSTEM

## BATTERY

Open the seat with key.

Remove the battery cover screw and the battery cover.

Remove the battery.

First disconnect the battery negative (-) cable and then the positive (+) cable.

- \* When disconnecting the battery positive (+) cable, do not touch the frame with tool; otherwise it will cause short circuit and sparks to fire the fuel.

The installation sequence is the reverse of removal.

- \* First connect the positive (+) cable and then negative (-) cable to avoid short circuit.

## BATTERY VOLTAGE INSPECTION (OPEN CIRCUIT VOLTAGE)

Disconnect the battery cables.

Measure the voltage between the battery terminals.

Fully charged : 13.2V

Undercharged : 12.3V max.

- \* Battery charging inspection must be performed with a voltmeter.

## CHARGING

Connect the charger positive (+) cable to the battery positive (+) terminal.

Connect the charger negative (-) cable to the battery negative (-) terminal.

- \*
  - Keep flames and sparks away from a charging battery.
  - Turn power ON/OFF at the charger, not at the battery terminals to prevent sparks near the battery.
  - Charge the battery according to the current specified on the battery.
  - During quick charging, the battery temperature should not exceed 45°C.

- \*
  - Quick charging should only be done in an emergency.
  - Measure the voltage 30 minutes after the battery is charged.


Charging current : Standard : 1.2A

Quick : 5A

Charging time : Standard : 5 - 10 hours

Quick : 60 minutes

After charging Open circuit voltage: 12.8V min.



# 16. BATTERY/CHARGING SYSTEM

## CHARGING SYSTEM

### CURRENT TEST

- \* Use a fully charged battery (12.8V min.) to check the charging system.

Warm up the engine before taking readings. Connect an electric tester across the battery terminals.

Disconnect the red wire from the fuse terminal and connect an ammeter between the red wire lead and the fuse terminal.


Attach a tachometer to the engine.

Start the engine and gradually increase the engine speed to measure the limit voltage and current.

**Limit Voltage/Current:** 14\_ 15V/0.5A  
max. (5000rpm max.)

If the limit voltage is not within the specified range, check the regulator/rectifier.

Red Wire



### PERFORMANCE TEST

Engine Speed	2500rpm	5000rpm
Charging Current	7A min.	9A min.

- \* When measuring the charging current, disconnect the black wire from the regulator/rectifier wire coupler.

If the readings do not meet the specified values, check the regulator/rectifier.

## A.C. GENERATOR INSPECTION

- \* This test can be made without removing the stator from the engine. Disconnect the yellow wire from the auto bystarter.

Remove the frame center cover.

Disconnect the A.C. generator connector.

Check the continuity between the yellow wires and ground.

There should be continuity between the yellow wires and no continuity between each yellow wire and ground.

**Resistance:**

Yellow_ Yellow	1.6_ 2.5Ω
----------------	-----------

A.C. Generator Connector




# 16. BATTERY/CHARGING SYSTEM

## A.C. GENERATOR REMOVAL

A.C. generator removal (⇒ 10-3)

A.C. generator installation (⇒ 10-6)



## REGULATOR/RECTIFIER


### INSPECTION

Remove the met-in box. (⇒ 2-6)

Remove the regulator/rectifier wire coupler.  
Check the continuity between the wire terminals.


Normal Direction: Continuity

	(+) Probe	(-) Probe
I	Yellow	Green
II	Red/White	Yellow



Reverse Direction: No Continuity

	(+) Probe	(-) Probe
I	Green	Yellow
II	Yellow	Red/White



## VOLTAGE REGULATION TEST

Connect a voltmeter across the battery terminals.

Start the engine and gradually increase the engine speed.

The battery terminal voltage should be within 14.0\_ 15.0V.

