


⚠ WARNING!

in case of parts substitution, apply
the info-decals contained in the decal-kit


• frame I

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Saddel support		R	-		RSV Mille 2000 + "R"
1	Saddel support		STD	-		RSV Mille 2000 + "R"
2	Threaded and rivet		-	-		RSV Mille 2000 + "R"
3	Rear fairing support		STD	-		RSV Mille 2000 + "R"
4	Cable-guide		-	-		RSV Mille 2000 + "R"
5	Hex socket screw	m10x30	-	-		RSV Mille 2000 + "R"
6	Pass.saddle connecting plate		R	-		RSV Mille 2000 + "R"
7	Spacer		R	-		RSV Mille 2000 + "R"




• frame II

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Coil support, RH		-	-		RSV Mille 2000 + "R"
2	Coil support, LH		-	-		RSV Mille 2000 + "R"
3	Instrum.holder frame		-	-		RSV Mille 2000 + "R"
4	Circlip	d8	-	-		RSV Mille 2000 + "R"
5	Fairing connecting plate		-	-		RSV Mille 2000 + "R"
6	Snap ring		-	-		RSV Mille 2000 + "R"
7	Fairing fixing plate		-	-		RSV Mille 2000 + "R"
8	Clip	M5*	-	-		RSV Mille 2000 + "R"
9	Clip	M6*	-	-		RSV Mille 2000 + "R"
10	Screw w/ flange	M5x12*	-	-		RSV Mille 2000 + "R"
11	Black cable guide		-	-		RSV Mille 2000 + "R"
12	Cable-guide		-	-		RSV Mille 2000 + "R"
13	Frame		-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
13	Frame		-	-	USA	RSV Mille 2000 + "R"
14	Min.eng.spd.cable plate		-	-		RSV Mille 2000 + "R"
15	Hose clamp		-	-		RSV Mille 2000 + "R"
16	Screw	m6x70*	-	-		RSV Mille 2000 + "R"
17	Self-locking nut	M6*	-	-		RSV Mille 2000 + "R"
18	Threaded and rivet		-	-		RSV Mille 2000 + "R"
19	Screw w/ flange	M6x16*	-	-		RSV Mille 2000 + "R"
20	Screw w/ flange	M6x20*	-	-		RSV Mille 2000 + "R"




• frame III

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Self-locking nut	M10*	-	-	-	RSV Mille 2000 + "R"
2	Screw w/ flange	m10x100	-	-	-	RSV Mille 2000 + "R"
3	Screw w/ flange	M10X35	-	-	-	RSV Mille 2000 + "R"
4	Screw w/ flange	m10x40	-	-	-	RSV Mille 2000 + "R"
5	Cable-guide	-	-	-	USA	RSV Mille 2000 + "R"
5	Cable-guide	-	-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
6	Curved spring washer	*	-	-	-	RSV Mille 2000 + "R"
7	Screw w/ flange	M6x16*	-	-	-	RSV Mille 2000 + "R"
8	Clip	M5*	-	-	-	RSV Mille 2000 + "R"
9	Clip	M6*	-	-	-	RSV Mille 2000 + "R"
10	Upper engine spacer	-	-	-	-	RSV Mille 2000 + "R"
11	Lower water cooler support	-	-	-	-	RSV Mille 2000 + "R"
12	Water cooler upper support	-	-	-	-	RSV Mille 2000 + "R"
13	Frame	-	-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
13	Frame	-	-	-	USA	RSV Mille 2000 + "R"
14	Lower adjustment bush	-	-	-	-	RSV Mille 2000 + "R"
15	Screw w/ flange	M6x16*	-	-	-	RSV Mille 2000 + "R"
16	Upper adjustment bush	-	-	-	-	RSV Mille 2000 + "R"
17	Eng.connect.elem.ring nut	-	-	-	-	RSV Mille 2000 + "R"
18	Threaded and rivet	-	-	-	-	RSV Mille 2000 + "R"
19	Conical bush	-	-	-	-	RSV Mille 2000 + "R"
20	Low self-locking nut	M6*	-	-	-	RSV Mille 2000 + "R"
21	Screw w/ flange	M6x30*	-	-	-	RSV Mille 2000 + "R"
22	Washer	-	-	-	-	RSV Mille 2000 + "R"
23	LH front engine spacer	-	-	-	-	RSV Mille 2000 + "R"
24	Screw w/ flange	m10x75	-	-	-	RSV Mille 2000 + "R"
25	Screw w/ flange	m10x110	-	-	-	RSV Mille 2000 + "R"
26	Black cable guide	-	-	-	-	RSV Mille 2000 + "R"




• foot rests

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Fairing fixing plate		-	-	-	RSV Mille 2000 + "R"
2	Footrest pin		-	-	-	RSV Mille 2000 + "R"
3	Footrest return spring		-	-	-	RSV Mille 2000 + "R"
4	Stop ring		-	-	-	RSV Mille 2000 + "R"
5	Front footrest, pair		-	-	-	RSV Mille 2000 + "R"
6	Screw w/ flange	M6x16*	-	-	-	RSV Mille 2000 + "R"
7	RH front footrest bracket		-	-	-	RSV Mille 2000 + "R"
8	LH front footrest bracket		-	-	-	RSV Mille 2000 + "R"
9	RH front footrest guard		-	-	-	RSV Mille 2000 + "R"
10	LH front footrest guard		-	-	-	RSV Mille 2000 + "R"
11	Coil compress. spring	*	STD	-	-	RSV Mille 2000 + "R"
12	Ball	D6,35	STD	-	-	RSV Mille 2000 + "R"
13	LH footrest support		STD	-	-	RSV Mille 2000 + "R"
14	RH footrest support		STD	-	-	RSV Mille 2000 + "R"
15	Rear footrests, pair		STD	-	-	RSV Mille 2000 + "R"
16	Screw w/ flange	M6x12*	-	-	-	RSV Mille 2000 + "R"
17	Footrest plate		STD	-	-	RSV Mille 2000 + "R"
18	Screw w/ flange	M8x30*	-	-	-	RSV Mille 2000 + "R"
19	Threaded and rivet		-	-	-	RSV Mille 2000 + "R"




• central stand

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Cavalletto cpl.		-	-	I-A-AUS-B-CH-D-DK-E- F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
1	Cavalletto cpl.		-	-	USA	RSV Mille 2000 + "R"
2	Cavalletto cpl.		-	-	USA	RSV Mille 2000 + "R"
2	Cavalletto laterale		-	-	I-A-AUS-B-CH-D-DK-E- F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
3	Piastra cavalletto		-	-	I-A-AUS-B-CH-D-DK-E- F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
3	Piastra cavalletto		-	-	USA	RSV Mille 2000 + "R"
4	Molla elica cilind.trazione	*	-	-	-	RSV Mille 2000 + "R"
5	Vite TE flangiata	m10x30	-	-	I-A-AUS-B-CH-D-DK-E- F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
5	Vite TCEI	m10x45	-	-	USA	RSV Mille 2000 + "R"
6	Dado basso	M10x1,25*	-	-	-	RSV Mille 2000 + "R"
7	Protezione molla cavalletto		-	-	-	RSV Mille 2000 + "R"
8	Vite cavalletto		-	-	I-A-AUS-B-CH-D-DK-E- F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
8	Vite cavalletto		-	-	USA	RSV Mille 2000 + "R"
9	Molla ritorno cavalletto		-	-	-	RSV Mille 2000 + "R"
10	Vite TE flangiata	M6x20*	-	-	-	RSV Mille 2000 + "R"
11	Rosetta	6,6x18x1,6*	-	-	-	RSV Mille 2000 + "R"
12	Rosetta elastica curva	*	-	-	-	RSV Mille 2000 + "R"
13	Interruttore rotativo		-	-	-	RSV Mille 2000 + "R"
14	Dado autobloc.basso	M10*	-	-	USA	RSV Mille 2000 + "R"
15	Vite TCEI	M10x95*	-	-	USA	RSV Mille 2000 + "R"




- steering

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Axial ball bearing		-	-	-	RSV Mille 2000 + "R"
2	Fork upper plate		STD	-	-	RSV Mille 2000 + "R"
2	Fork upper plate		R	-	-	RSV Mille 2000 + "R"
3	Stem base		R	-	-	RSV Mille 2000 + "R"
3	Stem base		STD	-	-	RSV Mille 2000 + "R"
4	Steering security plate		-	-	-	RSV Mille 2000 + "R"
5	Ring nut		-	-	-	RSV Mille 2000 + "R"
6	Return ring nut		-	-	-	RSV Mille 2000 + "R"
7	Dust cover ring		-	-	-	RSV Mille 2000 + "R"
8	Upper plate fixing bush		STD	-	-	RSV Mille 2000 + "R"
8	Upper plate fixing bush		R	-	-	RSV Mille 2000 + "R"
9	Steering lock bush		-	-	-	RSV Mille 2000 + "R"
10	Hex socket screw	M8x16*	-	-	-	RSV Mille 2000 + "R"
11	Dust cover ring		-	-	-	RSV Mille 2000 + "R"
12	Screw w/ flange	M8x35*	-	-	-	RSV Mille 2000 + "R"
13	Screw w/ flange	M6x30*	-	-	-	RSV Mille 2000 + "R"
14	Spacer	*	-	-	-	RSV Mille 2000 + "R"
15	Articulated head		STD	-	-	RSV Mille 2000 + "R"
16	Steering shockabs.union		STD	-	-	RSV Mille 2000 + "R"
17	Hex socket screw	M6x12*	STD	-	-	RSV Mille 2000 + "R"
18	Circlip		STD	-	-	RSV Mille 2000 + "R"
19	T bush		STD	-	-	RSV Mille 2000 + "R"
20	O-ring	119	STD	-	-	RSV Mille 2000 + "R"
21	Ball joint		STD	-	-	RSV Mille 2000 + "R"
22	Steering shockabs. collar		STD	-	-	RSV Mille 2000 + "R"
23	Steering shock absorber		R	-	-	RSV Mille 2000 + "R"
23	Steering shock absorber		STD	-	-	RSV Mille 2000 + "R"
24	Stem plug washer		-	-	-	RSV Mille 2000 + "R"
25	"Aprilia" dataplate		-	-	-	RSV Mille 2000 + "R"
26	Dowel	m5 l.8	-	-	-	RSV Mille 2000 + "R"





• front fork I

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	RH hub	STD	-	-		RSV Mille 2000 + "R"
1	RH hub	R	-	-		RSV Mille 2000 + "R"
2	LH hub	STD	-	-		RSV Mille 2000 + "R"
2	LH hub	R	-	-		RSV Mille 2000 + "R"
3	Sleeve	STD	-	-		RSV Mille 2000 + "R"
4	Plunger attachment bush	STD	-	-		RSV Mille 2000 + "R"
5	Spring	STD	-	-		RSV Mille 2000 + "R"
6	Preload tube cpl.	STD	-	-		RSV Mille 2000 + "R"
7	Spacer	STD	-	-		RSV Mille 2000 + "R"
8	Washer	STD	-	-		RSV Mille 2000 + "R"
9	Plunger, complete	STD	-	-		RSV Mille 2000 + "R"
10	Washer	STD	-	-		RSV Mille 2000 + "R"
11	Ring	STD	-	-		RSV Mille 2000 + "R"
12	Sleeve plug cpl.	STD	-	-		RSV Mille 2000 + "R"
13	O-ring	STD	-	-		RSV Mille 2000 + "R"
14	O-ring	STD	-	-		RSV Mille 2000 + "R"
15	O-ring	STD	-	-		RSV Mille 2000 + "R"
16	Stop ring	STD	-	-		RSV Mille 2000 + "R"



• front fork II

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	RH hub		STD	-	-	RSV Mille 2000 + "R"
1	RH hub		R	-	-	RSV Mille 2000 + "R"
2	LH hub		STD	-	-	RSV Mille 2000 + "R"
2	LH hub		R	-	-	RSV Mille 2000 + "R"
3	Screw w/ flange	M8x40*	-	-	-	RSV Mille 2000 + "R"
4	Hub+RH fork leg		STD	-	-	RSV Mille 2000 + "R"
5	Hub+LH fork leg		STD	-	-	RSV Mille 2000 + "R"
6	Dust cover		STD	-	-	RSV Mille 2000 + "R"
7	Circlip		STD	-	-	RSV Mille 2000 + "R"
8	Oil seal		STD	-	-	RSV Mille 2000 + "R"
9	Bush		STD	-	-	RSV Mille 2000 + "R"
10	Bush		STD	-	-	RSV Mille 2000 + "R"
11	Ring		STD	-	-	RSV Mille 2000 + "R"
12	Special washer		STD	-	-	RSV Mille 2000 + "R"
13	Screw	M10x1,5	STD	-	-	RSV Mille 2000 + "R"



⚠️ WARNING!


in case of parts substitution, apply
the info-decals contained in the decal-kit

• swing arm

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Ball bearing		-	-	-	RSV Mille 2000 + "R"
2	Rear swing arm pin		-	-	-	RSV Mille 2000 + "R"
3	RH chain guide plate		-	-	-	RSV Mille 2000 + "R"
4	LH chain guide plate		-	-	-	RSV Mille 2000 + "R"
5	Adjustment bush		-	-	-	RSV Mille 2000 + "R"
6	Swing arm ring nut		-	-	-	RSV Mille 2000 + "R"
7	Internal spacer		-	-	-	RSV Mille 2000 + "R"
8	Rear int.sw.arm piv.bush		-	-	-	RSV Mille 2000 + "R"
9	Rear stand bush		-	-	-	RSV Mille 2000 + "R"
10	Swing arm		-	-	-	RSV Mille 2000 + "R"
11	Needle bearing		-	-	-	RSV Mille 2000 + "R"
12	Gasket ring		-	-	-	RSV Mille 2000 + "R"
13	Rear wheel spindle nut		-	-	-	RSV Mille 2000 + "R"
14	O-ring	134	-	-	-	RSV Mille 2000 + "R"
15	Inside circlip	d37	-	-	-	RSV Mille 2000 + "R"
16	Gasket ring		-	-	-	RSV Mille 2000 + "R"
17	Wheel pin washer		-	-	-	RSV Mille 2000 + "R"
18	Screw	m6x40	-	-	-	RSV Mille 2000 + "R"
19	Serpress nut	M8	-	-	-	RSV Mille 2000 + "R"
20	Chain tens.adjuster screw		-	-	-	RSV Mille 2000 + "R"
21	Threaded rivet	M5	-	-	-	RSV Mille 2000 + "R"
22	Chain guide plate		-	-	-	RSV Mille 2000 + "R"
23	Chain guard		-	-	-	RSV Mille 2000 + "R"
24	Cup for shoe		-	-	-	RSV Mille 2000 + "R"
25	Screw w/ flange	M5x12*	-	-	-	RSV Mille 2000 + "R"
26	Hex socket screw	M5x12*	-	-	-	RSV Mille 2000 + "R"
27	Adhesive sponge		-	-	-	RSV Mille 2000 + "R"
28	Chain guide plate	STD	-	-	USA	RSV Mille 2000 + "R"
28	Chain guide plate	R	-	-	-	RSV Mille 2000 + "R"
29	T bush	*	-	-	-	RSV Mille 2000 + "R"
30	Screw w/ flange	M5x12*	-	-	-	RSV Mille 2000 + "R"


⚠ WARNING!

in case of parts substitution, apply
the info-decals contained in the decal-kit



• connection rod - rear shock abs.

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Double connecting rod pin		-	-	-	RSV Mille 2000 + "R"
2	Needle bearing		-	-	-	RSV Mille 2000 + "R"
3	Single conrod comp.		-	-	-	RSV Mille 2000 + "R"
4	Shock absorber	STD	-	-	-	RSV Mille 2000 + "R"
4	Shock absorber	R	-	-	-	RSV Mille 2000 + "R"
5	Double conrod		-	-	-	RSV Mille 2000 + "R"
6	Screw w/ flange	m10x65	-	-	-	RSV Mille 2000 + "R"
7	Self-locking nut	M10*	-	-	-	RSV Mille 2000 + "R"
8	Hex socket screw	m10x63	-	-	-	RSV Mille 2000 + "R"
9	Hex socket screw	m10x74	-	-	-	RSV Mille 2000 + "R"
10	T bush	*	-	-	-	RSV Mille 2000 + "R"
11	Oil seal	D18x24x3	-	-	-	RSV Mille 2000 + "R"
12	T bush		-	-	-	RSV Mille 2000 + "R"
13	O-ring		-	-	-	RSV Mille 2000 + "R"
14	Return ring nut		-	-	-	RSV Mille 2000 + "R"
15	Ring nut		-	-	-	RSV Mille 2000 + "R"
16	Plug		-	-	-	RSV Mille 2000 + "R"
17	T bush		-	-	-	RSV Mille 2000 + "R"




RSV Mille "R" version

WARNING!

In case of parts substitution, apply
the info-decals contained in the decal-kit


• front body - front fairing

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION 1	COUNTRY	MODEL
1	Screw w/ flange	M5x16*	-	-		RSV Mille 2000 + "R"
2	Screw w/ flange	M6x16*	-	-		RSV Mille 2000 + "R"
3	Windshield		STD	-	I-E-P-B-GR-UK-D-NL-F-A-J-DK-CH	RSV Mille 2000 + "R"
3	Windshield		R	-	I-E-P-B-GR-UK-D-NL-F-A-J-DK-CH	RSV Mille 2000 + "R"
3	Windshield		-	-	AUS-USA	RSV Mille 2000 + "R"
4	Fairing holder pin		-	-		RSV Mille 2000 + "R"
5	Gasket		-	-		RSV Mille 2000 + "R"
6	Washer for shafts	D5	-	-		RSV Mille 2000 + "R"
7	Mirror joint cup		-	-		RSV Mille 2000 + "R"
8	RH rearview mirror		-	-		RSV Mille 2000 + "R"
9	LH rearview mirror		-	-		RSV Mille 2000 + "R"
10	Mirror insertion kit		-	-		RSV Mille 2000 + "R"
11	Front fairing, ap.black		-	black		RSV Mille 2000 + "R"
11	Front fairing, hot red		-	red		RSV Mille 2000 + "R"
11	Front fairing, el.blue		-	blue		RSV Mille 2000 + "R"
11	Front fairing, f.yellow		-	yell		RSV Mille 2000 + "R"
11	Front fairing, black/white		-	rac		RSV Mille 2000 + "R"
12	Front fairing-dashboard lockup		-	black-blue-red-yell		RSV Mille 2000 + "R"
12	Front fairing-dashboard lockup		-	rac		RSV Mille 2000 + "R"
13	Front fairing gasket	R	-	-		RSV Mille 2000 + "R"
14	Staple	R	-	-		RSV Mille 2000 + "R"




• front body - duct

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Duct	-	-	-	-	RSV Mille 2000 + "R"
2	Air temp. Sensor	-	-	-	-	RSV Mille 2000 + "R"
3	Screw w/ flange	M6x20*	-	-	-	RSV Mille 2000 + "R"
4	Air intake grid, RH	-	-	-	-	RSV Mille 2000 + "R"
5	Air intake grid, LH	-	-	-	-	RSV Mille 2000 + "R"
6	Self-tapping screw	*	-	-	-	RSV Mille 2000 + "R"
7	Expansion insert	m5	-	-	-	RSV Mille 2000 + "R"
8	Screw w/ flange	M5x16*	-	-	-	RSV Mille 2000 + "R"
9	Cable-guide	-	-	-	-	RSV Mille 2000 + "R"
10	Clip	M5*	-	-	-	RSV Mille 2000 + "R"
11	LH ext.air duct, black	-	black	-	-	RSV Mille 2000 + "R"
11	LH ext.air duct, a.black	-	rac	-	-	RSV Mille 2000 + "R"
11	LH ext.air duct, yellow	-	yell	-	-	RSV Mille 2000 + "R"
11	LH ext.air duct, el.blue	-	blue	-	-	RSV Mille 2000 + "R"
11	LH ext.air duct, hot red	-	red	-	-	RSV Mille 2000 + "R"
12	RH ext.air duct, a.black	-	black	-	-	RSV Mille 2000 + "R"
12	RH ext.air duct, hot red	-	red	-	-	RSV Mille 2000 + "R"
12	RH ext.air duct, el.blue	-	blue	-	-	RSV Mille 2000 + "R"
12	RH ext.air duct, yellow	-	yell	-	-	RSV Mille 2000 + "R"
12	RH ext.air duct, a.black	-	rac	-	-	RSV Mille 2000 + "R"
13	RH int.air duct, el.blue	-	blue	-	-	RSV Mille 2000 + "R"
13	RH int.air duct, yellow	-	yell	-	-	RSV Mille 2000 + "R"
13	RH int.air duct, hot red	-	red	-	-	RSV Mille 2000 + "R"
13	RH int.air duct, black	-	black-rac	-	-	RSV Mille 2000 + "R"
14	LH int.air duct, hot red	-	red	-	-	RSV Mille 2000 + "R"
14	LH int.air duct, el.blue	-	blue	-	-	RSV Mille 2000 + "R"
14	LH int.air duct, yellow	-	yell	-	-	RSV Mille 2000 + "R"
14	LH int.air duct, black	-	black-rac	-	-	RSV Mille 2000 + "R"




• front body - front mudguard

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Front mudguard, el.blue		-	blue	I-E-UK-J-P-B-GR-AUS-A-DK-CH-D-NL-F	RSV Mille 2000 + "R"
1	Front mudguard, carb.		-	rac	I-E-UK-J-P-B-GR-AUS-A-DK-CH-D-NL-F	RSV Mille 2000 + "R"
1	Front mudguard, fl.yellow		-	yell	USA	RSV Mille 2000 + "R"
1	Front mudguard, carb.		-	rac	USA	RSV Mille 2000 + "R"
1	Front mudguard, el.blue		-	blue	USA	RSV Mille 2000 + "R"
1	Front mudguard, hot red		-	red	I-E-UK-J-P-B-GR-AUS-A-DK-CH-D-NL-F	RSV Mille 2000 + "R"
1	Front mudguard, ap.black		-	black	USA	RSV Mille 2000 + "R"
1	Front mudguard, ap.black		-	black	I-E-UK-J-P-B-GR-AUS-A-DK-CH-D-NL-F	RSV Mille 2000 + "R"
1	Front mudguard, fl.yellow		-	yell	I-E-UK-J-P-B-GR-AUS-A-DK-CH-D-NL-F	RSV Mille 2000 + "R"
1	Front mudguard, hot red		-	red	USA	RSV Mille 2000 + "R"
2	Curved spring washer	*	R	-	-	RSV Mille 2000 + "R"
3	Low self-locking nut	M4*	-	-	USA	RSV Mille 2000 + "R"
4	Screw w/ flange	M5x16*	-	-	-	RSV Mille 2000 + "R"
5	LH Front reflector support		-	-	USA	RSV Mille 2000 + "R"
6	RH Front reflector support		-	-	USA	RSV Mille 2000 + "R"
7	Reflector, amber		-	-	USA	RSV Mille 2000 + "R"




• front body - lockups

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Screw w/ flange	M6x12*	-	-	-	RSV Mille 2000 + "R"
2	Screw w/ flange	M6x16*	-	-	-	RSV Mille 2000 + "R"
3	Spoiler heat protection		-	-	-	RSV Mille 2000 + "R"
4	Front fairing lower lockup		-	-	-	RSV Mille 2000 + "R"
5	Pillar, fluo red		-	black-rac	-	RSV Mille 2000 + "R"
5	Pillar, anod.grey		-	blue-red-yell	-	RSV Mille 2000 + "R"
6	Water cooler spoiler, an.grey		-	-	-	RSV Mille 2000 + "R"




• central body - upper fairings

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Rubber spacer		-	-	-	RSV Mille 2000 + "R"
2	Rubber w/ insert	*	-	-	-	RSV Mille 2000 + "R"
3	Self-tapping screw	*	-	-	-	RSV Mille 2000 + "R"
4	RH lat.fairing, black	-	black	-	-	RSV Mille 2000 + "R"
4	RH lat.fairing, black	-	rac	-	-	RSV Mille 2000 + "R"
4	RH lat.fairing, fl.yellow	-	yell	-	-	RSV Mille 2000 + "R"
4	RH lat.fairing, hot red	-	red	-	-	RSV Mille 2000 + "R"
4	RH lat.fairing, el.blue	-	blue	-	-	RSV Mille 2000 + "R"
5	LH lat.fairing, black	-	black	-	-	RSV Mille 2000 + "R"
5	LH lat.fairing, hot red	-	red	-	-	RSV Mille 2000 + "R"
5	LH lat.fairing, el.blue	-	blue	-	-	RSV Mille 2000 + "R"
5	LH lat.fairing, fl.yellow	-	yell	-	-	RSV Mille 2000 + "R"
5	LH lat.fairing, black	-	rac	-	-	RSV Mille 2000 + "R"
6	RH internal fairing, black	-	-	-	-	RSV Mille 2000 + "R"
7	LH internal fairing, black	-	-	-	-	RSV Mille 2000 + "R"
8	Upper RH fairing, black	-	black-rac	-	-	RSV Mille 2000 + "R"
8	Upper RH fairing, yellow	-	yell	-	-	RSV Mille 2000 + "R"
8	Upper RH fairing, red	-	red	-	-	RSV Mille 2000 + "R"
8	Upper RH fairing, blue	-	blue	-	-	RSV Mille 2000 + "R"
9	Upper LH fairing, black	-	black-rac	-	-	RSV Mille 2000 + "R"
9	Upper LH fairing, red	-	red	-	-	RSV Mille 2000 + "R"
9	Upper LH fairing, blue	-	blue	-	-	RSV Mille 2000 + "R"
9	Upper LH fairing, yellow	-	yell	-	-	RSV Mille 2000 + "R"
10	Front dust cover ring	-	-	-	-	RSV Mille 2000 + "R"
11	Acoustic insul. panel, RH up.	-	-	-	-	RSV Mille 2000 + "R"
12	Acoustic insul. panel, LH up.	-	-	-	-	RSV Mille 2000 + "R"
13	Pin	-	-	-	-	RSV Mille 2000 + "R"
14	Screw w/ flange	M5x12*	-	-	-	RSV Mille 2000 + "R"



• central body - RH fairings

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Silencer protection		-	-	-	RSV Mille 2000 + "R"
2	RH lower fairing, fluo red		-	black	-	RSV Mille 2000 + "R"
2	RH lower fairing, anod.grey		-	red	-	RSV Mille 2000 + "R"
2	RH lower fairing, anod.grey		-	blue	-	RSV Mille 2000 + "R"
2	RH lower fairing, anod.grey		-	yell	-	RSV Mille 2000 + "R"
2	RH lower fairing, fluo red		-	rac	-	RSV Mille 2000 + "R"
3	Acoustic insul. panel, RH low.		-	-	-	RSV Mille 2000 + "R"
4	Side panel support rubber		-	-	-	RSV Mille 2000 + "R"
5	Clip	M6*	-	-	-	RSV Mille 2000 + "R"
6	Screw w/ flange	M6x16*	-	-	-	RSV Mille 2000 + "R"
7	Fairing holder pin		-	-	-	RSV Mille 2000 + "R"
8	Gasket		-	-	-	RSV Mille 2000 + "R"
9	Washer for shafts	D5	-	-	-	RSV Mille 2000 + "R"
10	Special clip		-	-	-	RSV Mille 2000 + "R"
11	Acoustic insul. panel, LH low.		-	-	-	RSV Mille 2000 + "R"




• central body - LH fairings

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Silencer protection		-	-	-	RSV Mille 2000 + "R"
2	Acoustic insul. panel, RH low.		-	-	-	RSV Mille 2000 + "R"
3	LH lower fairing, anod.grey		-	red	I-E-UK-J-P-B-GR-AUS-A-DK-CH-D-NL-F	RSV Mille 2000 + "R"
3	LH lower fairing, fluo red		-	rac	I-E-UK-J-P-B-GR-AUS-A-DK-CH-D-NL-F	RSV Mille 2000 + "R"
3	LH lower fairing, anod.grey		-	yell	USA	RSV Mille 2000 + "R"
3	LH lower fairing, fluo red		-	rac	USA	RSV Mille 2000 + "R"
3	LH lower fairing, anod.grey		-	yell	I-E-UK-J-P-B-GR-AUS-A-DK-CH-D-NL-F	RSV Mille 2000 + "R"
3	LH lower fairing, anod.grey		-	red	USA	RSV Mille 2000 + "R"
3	LH lower fairing, fluo red		-	black	USA	RSV Mille 2000 + "R"
3	LH lower fairing, fluo red		-	black	I-E-UK-J-P-B-GR-AUS-A-DK-CH-D-NL-F	RSV Mille 2000 + "R"
3	LH lower fairing, anod.grey		-	blue	I-E-UK-J-P-B-GR-AUS-A-DK-CH-D-NL-F	RSV Mille 2000 + "R"
3	LH lower fairing, anod.grey		-	blue	USA	RSV Mille 2000 + "R"
4	Side panel support rubber		-	-	-	RSV Mille 2000 + "R"
5	Clip	M6*	-	-	-	RSV Mille 2000 + "R"
6	Screw w/ flange	M6x16*	-	-	-	RSV Mille 2000 + "R"
7	Fairing holder pin		-	-	-	RSV Mille 2000 + "R"
8	Gasket		-	-	-	RSV Mille 2000 + "R"
9	Washer for shafts	D5	-	-	-	RSV Mille 2000 + "R"
10	Special clip		-	-	-	RSV Mille 2000 + "R"
11	Acoustic insul. panel, LH low.		-	-	-	RSV Mille 2000 + "R"


⚠ WARNING!

in case of parts substitution, apply
the info-decals contained in the decal-kit




• fuel tank

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Tank support		-	-	-	RSV Mille 2000 + "R"
2	F.Tank acoustic insul. Panel		STD	-	-	RSV Mille 2000 + "R"
2	F.Tank acoustic insul. Panel		R	-	-	RSV Mille 2000 + "R"
3	Screw w/ flange	M6x16*	-	-	-	RSV Mille 2000 + "R"
4	Fuel filler cap		-	-	-	RSV Mille 2000 + "R"
5	Fuel tank, Ap. black		-	rac	-	RSV Mille 2000 + "R"
5	Fuel tank, flashy yellow		-	yell	-	RSV Mille 2000 + "R"
5	Fuel tank, Ap. black		-	black	-	RSV Mille 2000 + "R"
5	Fuel tank, hot red		-	red	-	RSV Mille 2000 + "R"
5	Fuel tank, el.blue		-	blue	-	RSV Mille 2000 + "R"
6	Hex socket screw	m5x16	-	-	-	RSV Mille 2000 + "R"
7	Hex socket screw	m5x30	-	-	-	RSV Mille 2000 + "R"
8	T bush	*	STD	-	-	RSV Mille 2000 + "R"
8	T bush		R	-	-	RSV Mille 2000 + "R"
9	Rubber spacer	*	STD	-	-	RSV Mille 2000 + "R"
9	Rubber spacer		R	-	-	RSV Mille 2000 + "R"
10	Rubber spacer		R	-	-	RSV Mille 2000 + "R"
10	Tank rubber		STD	-	-	RSV Mille 2000 + "R"
11	Fuel tank bush		-	-	-	RSV Mille 2000 + "R"
12	Self-locking nut	M6*	-	-	-	RSV Mille 2000 + "R"
13	Washer	6,4x12,5*	-	-	-	RSV Mille 2000 + "R"
14	Hex screw	m6x90	-	-	-	RSV Mille 2000 + "R"
15	Screw w/ flange	M6x25*	STD	-	-	RSV Mille 2000 + "R"
15	Screw w/ flange	M6x30*	R	-	-	RSV Mille 2000 + "R"
16	Fuel tank heat protection		-	-	-	RSV Mille 2000 + "R"
17	Cap seal		R	-	-	RSV Mille 2000 + "R"
18	Fuel tank gasket		R	-	-	RSV Mille 2000 + "R"
19	Float chamber		R	-	-	RSV Mille 2000 + "R"
20	Hose holder union		R	-	-	RSV Mille 2000 + "R"
21	O-ring	2018	R	-	-	RSV Mille 2000 + "R"
22	Rubber spacer		R	-	-	RSV Mille 2000 + "R"




• fuel vapour recover system

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	"Y" union		-	-	USA	RSV Mille 2000 + "R"
2	Anti-return valve		-	-	USA	RSV Mille 2000 + "R"
3	Choke hold		-	-	USA	RSV Mille 2000 + "R"
4	3-way union		-	-	USA	RSV Mille 2000 + "R"
5	3-way union		-	-	USA	RSV Mille 2000 + "R"
6	"Purge" valve		-	-	USA	RSV Mille 2000 + "R"
7	Carbon filter		-	-	USA	RSV Mille 2000 + "R"
8	Valve support clamp		-	-	USA	RSV Mille 2000 + "R"
9	Adhesive sponge		-	-	USA	RSV Mille 2000 + "R"
10	Hose clamp	d.76	-	-	USA	RSV Mille 2000 + "R"
11	Hose clamp	d.80,5	-	-	USA	RSV Mille 2000 + "R"
12	Clip	M5*	-	-	USA	RSV Mille 2000 + "R"
13	Screw w/ flange	M5x16*	-	-	USA	RSV Mille 2000 + "R"
14	Washer	5,5x15x1,6*	-	-	USA	RSV Mille 2000 + "R"
15	Fuel pipe	5,5x10	-	-	USA	RSV Mille 2000 + "R"
16	Oil breather pipe	9x14	-	-	USA	RSV Mille 2000 + "R"
17	Pipe	4x8	-	-	USA	RSV Mille 2000 + "R"
18	Hose clamp	D10,1*	-	-	USA	RSV Mille 2000 + "R"
19	Hose clamp		-	-	USA	RSV Mille 2000 + "R"
20	Hose clamp	D11,3	-	-	USA	RSV Mille 2000 + "R"
21	Hose clamp	D8*	-	-	USA	RSV Mille 2000 + "R"
22	Hose clamp	D9,1*	-	-	USA	RSV Mille 2000 + "R"
23	Hose clamp	d.15,8	-	-	USA	RSV Mille 2000 + "R"
24	Self-locking nut	M6*	-	-	USA	RSV Mille 2000 + "R"
25	Screw w/ flange	M6x20*	-	-	USA	RSV Mille 2000 + "R"




• saddle

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Driver saddle, black		-	-		RSV Mille 2000 + "R"
2	Rear saddle, black		STD	-		RSV Mille 2000 + "R"
3	Pillion seat strap		STD	-		RSV Mille 2000 + "R"
4	Screw w/ flange	M6x20*	-	-		RSV Mille 2000 + "R"
5	Saddle cover, hot red		-	red		RSV Mille 2000 + "R"
5	Saddle cover, black/grey		-	rac		RSV Mille 2000 + "R"
5	Saddle cover, el.blue		-	blue		RSV Mille 2000 + "R"
5	Saddle cover, aprilia black		-	black		RSV Mille 2000 + "R"
5	Saddle cover, flashy yellow		-	yell		RSV Mille 2000 + "R"
6	Saddle cover base		-	-		RSV Mille 2000 + "R"
7	RH side panel, ap.black		-	black		RSV Mille 2000 + "R"
7	RH side panel, hot red		-	red		RSV Mille 2000 + "R"
7	RH side panel, el.blue		-	blue		RSV Mille 2000 + "R"
7	RH side panel, fl.yellow		-	yell		RSV Mille 2000 + "R"
7	RH side panel, grey		-	rac		RSV Mille 2000 + "R"
8	LH side panel, fl.yellow		-	yell		RSV Mille 2000 + "R"
8	LH side panel, grey		-	rac		RSV Mille 2000 + "R"
8	LH side panel, hot red		-	red		RSV Mille 2000 + "R"
8	LH side panel, ap.black		-	black		RSV Mille 2000 + "R"
8	LH side panel, el.blue		-	blue		RSV Mille 2000 + "R"
9	Saddle rubber		-	-		RSV Mille 2000 + "R"
10	Saddle rubber		-	-		RSV Mille 2000 + "R"
11	Side panel support rubber		-	-		RSV Mille 2000 + "R"
12	Screw w/ flange	M6x16*	-	-		RSV Mille 2000 + "R"
13	Self-tapping screw	*	-	-		RSV Mille 2000 + "R"
14	Bush	STD	-	-		RSV Mille 2000 + "R"
15	Frame ground bush		-	-		RSV Mille 2000 + "R"
16	Saddle rubber		-	-		RSV Mille 2000 + "R"
17	Saddle cover access door		-	-		RSV Mille 2000 + "R"
18	Adhesive sponge		-	-		RSV Mille 2000 + "R"




• rear body - rear fairing

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Fuel tank support rod		-	-		RSV Mille 2000 + "R"
2	Bush		-	-		RSV Mille 2000 + "R"
3	Hex socket screw	m6x35*	-	-		RSV Mille 2000 + "R"
4	Light supp.rear fair., a.grey		-	black-blue		RSV Mille 2000 + "R"
4	Light supp.rear fair., a.black		-	rac-red-yell		RSV Mille 2000 + "R"
5	Screw w/ flange	M6x16*	-	-		RSV Mille 2000 + "R"
6	Screw w/ flange	M5x12*	-	-		RSV Mille 2000 + "R"
7	Pass.saddle connecting plate		-	-		RSV Mille 2000 + "R"
8	Lock cable		-	-		RSV Mille 2000 + "R"
9	Clip	M5*	-	-		RSV Mille 2000 + "R"
10	Rear fairing, grey/red		-	rac		RSV Mille 2000 + "R"
10	Rear fairing, flashy yellow		-	yell		RSV Mille 2000 + "R"
10	Rear fairing, Ap.Black		-	black		RSV Mille 2000 + "R"
10	Rear fairing, el.blue		-	blue		RSV Mille 2000 + "R"
10	Rear fairing, hot red		-	red		RSV Mille 2000 + "R"
11	Saddle lock cpl.		-	-		RSV Mille 2000 + "R"




• undersaddle

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Saddle supp.lower lockup		-	black-blue-red-yell	I-E-UK-J-P-B-GR-AUS-A-DK-CH-D-NL-F	RSV Mille 2000 + "R"
1	Saddle supp.lower lockup		-	black-blue-red-yell	USA	RSV Mille 2000 + "R"
1	Saddle supp.low. lockup, red		-	rac	I-E-UK-J-P-B-GR-AUS-A-DK-CH-D-NL-F	RSV Mille 2000 + "R"
1	Saddle supp.low. lockup, red		-	rac	USA	RSV Mille 2000 + "R"
2	Hose clamp	D10,1*	-	-	-	RSV Mille 2000 + "R"
3	Fuel pipe	5,5x10	-	-	-	RSV Mille 2000 + "R"
4	Hose clamp		-	-	-	RSV Mille 2000 + "R"
5	Screw	m6x40	STD	-	-	RSV Mille 2000 + "R"
6	Rear stand bush		STD	-	-	RSV Mille 2000 + "R"
7	Rubber spacer		-	-	-	RSV Mille 2000 + "R"
8	Screw w/ flange	M6x16*	-	-	-	RSV Mille 2000 + "R"
9	Screw w/ flange	M6x16*	-	-	-	RSV Mille 2000 + "R"
10	Self-locking nut	M6*	-	-	-	RSV Mille 2000 + "R"
11	Clip	M5*	-	-	-	RSV Mille 2000 + "R"
12	Clip	M6*	-	-	-	RSV Mille 2000 + "R"
13	Plug		-	-	I-E-UK-J-P-B-GR-AUS-A-DK-CH-D-NL-F	RSV Mille 2000 + "R"




• rear mudguard

1	Number plate support	-	-	-	RSV Mille 2000 + "R"
2	Rear mudguard, carb.	-	rac	-	RSV Mille 2000 + "R"
2	Low rear mudguard	-	black-blue-red-yell	-	RSV Mille 2000 + "R"
3	Reflector support	-	-	-	RSV Mille 2000 + "R"
4	Rear reflector, red	-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
4	Rear reflector, red	-	-	USA	RSV Mille 2000 + "R"
5	Self-locking nut	M5*	-	USA	RSV Mille 2000 + "R"
6	Number-plate extension	-	-	A-CH-D-DK-NL	RSV Mille 2000 + "R"
7	Hex socket screw	M6x12*	-	-	RSV Mille 2000 + "R"
8	Curved spring washer	*	R	-	RSV Mille 2000 + "R"
9	Washer	5,3x10x1*	-	-	RSV Mille 2000 + "R"
10	Number plate holder	-	-	USA	RSV Mille 2000 + "R"
11	Screw w/ flange	M5x16*	-	-	RSV Mille 2000 + "R"
12	Self-locking nut	M6*	-	-	RSV Mille 2000 + "R"
13	Screw w/ flange	M6x16*	-	-	RSV Mille 2000 + "R"
14	Self-locking nut	M5*	-	-	RSV Mille 2000 + "R"
15	Hex socket screw	M5x12*	-	-	RSV Mille 2000 + "R"
16	Rear reflector support	-	-	USA	RSV Mille 2000 + "R"
17	Hex socket screw	M5x16*	-	USA	RSV Mille 2000 + "R"
18	Low self-locking nut	M4*	-	USA	RSV Mille 2000 + "R"




• **dashboard**

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Dashboard complete		-	-	-	RSV Mille 2000 + "R"
2	Rubber spacer	*	-	-	-	RSV Mille 2000 + "R"
3	Self-locking nut	M6*	-	-	-	RSV Mille 2000 + "R"
4	Lampholder, complete	12v/1,2w	-	-	-	RSV Mille 2000 + "R"
5	Lampholder, complete	12v/2w	-	-	-	RSV Mille 2000 + "R"
6	Lampholder, complete	12v/3w	-	-	-	RSV Mille 2000 + "R"
7	Dashboard piston		-	-	-	RSV Mille 2000 + "R"
8	Dashboard rubber		-	-	-	RSV Mille 2000 + "R"
9	Up. Dashboard cover		-	-	-	RSV Mille 2000 + "R"
10	Screw		-	-	-	RSV Mille 2000 + "R"




• handlebar

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Anti.v weight, black		-	-		RSV Mille 2000 + "R"
2	Right half handlebar		R	-		RSV Mille 2000 + "R"
2	Right half handlebar		STD	-		RSV Mille 2000 + "R"
3	Left half handlebar		R	-		RSV Mille 2000 + "R"
3	Left half handlebar		STD	-		RSV Mille 2000 + "R"
4	Anti v. weight shaft		-	-		RSV Mille 2000 + "R"
5	Rubber spacer		-	-		RSV Mille 2000 + "R"
6	Anti vib.weight trailing		-	-		RSV Mille 2000 + "R"
7	Screw w/ flange	M6x20*	-	-		RSV Mille 2000 + "R"
8	Handgrip pair, black		-	-		RSV Mille 2000 + "R"
9	Roller	D4x19,8	-	-		RSV Mille 2000 + "R"
10	O-ring	112	-	-		RSV Mille 2000 + "R"
11	Hex socket screw	M6x12*	-	-		RSV Mille 2000 + "R"
12	Screw w/ flange	M8x35*	-	-		RSV Mille 2000 + "R"
13	LH lights selector		-	-	I-A-AUS-B-CH-D-DK-E-F-GR-NL-P-UK J-USA	RSV Mille 2000 + "R"
13	LH lights selector		-	-	J-USA	RSV Mille 2000 + "R"
14	Choke control		-	-		RSV Mille 2000 + "R"
15	Engine stop-start device		-	-		RSV Mille 2000 + "R"
16	Gas fastener		-	-		RSV Mille 2000 + "R"
17	Gas fastener		-	-		RSV Mille 2000 + "R"
18	Choke cable		-	-		RSV Mille 2000 + "R"
19	Front gas lever U-bolt		-	-		RSV Mille 2000 + "R"
20	Rear gas lever U-bolt		-	-		RSV Mille 2000 + "R"
21	Cap screw		-	-		RSV Mille 2000 + "R"
22	TSPEI inox screw	m3x20	-	-		RSV Mille 2000 + "R"
23	O-ring	3075	-	-		RSV Mille 2000 + "R"




• clutch pump

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Oil tank plate		-	-	-	RSV Mille 2000 + "R"
2	Copper washer		-	-	-	RSV Mille 2000 + "R"
3	Oil pipe screw	*	-	-	-	RSV Mille 2000 + "R"
4	Bored screw		-	-	-	RSV Mille 2000 + "R"
5	Bleed valve cap		-	-	-	RSV Mille 2000 + "R"
6	Air bleed valve		-	-	-	RSV Mille 2000 + "R"
7	Clutch lever		-	-	-	RSV Mille 2000 + "R"
8	U-bolt		-	-	-	RSV Mille 2000 + "R"
9	Clutch pump		-	-	-	RSV Mille 2000 + "R"
10	Clutch pipe		-	-	-	RSV Mille 2000 + "R"
11	Rear brake pump union		-	-	-	RSV Mille 2000 + "R"
12	Lever pin		-	-	-	RSV Mille 2000 + "R"
13	Clutch command cylinder		-	-	-	RSV Mille 2000 + "R"
14	Pipe		-	-	-	RSV Mille 2000 + "R"
15	Hose clamp		-	-	-	RSV Mille 2000 + "R"
16	Screw w/ flange	M5x16*	-	-	-	RSV Mille 2000 + "R"
17	Self-locking nut	M5*	-	-	-	RSV Mille 2000 + "R"
18	Screw w/ flange	M6x12*	-	-	-	RSV Mille 2000 + "R"




• front brake pump

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
8	Lever pin	-	-	-	-	RSV Mille 2000 + "R"
9	Copper washer	-	-	-	-	RSV Mille 2000 + "R"
10	Oil pipe screw	*	-	-	-	RSV Mille 2000 + "R"
11	Oil tank plate	-	-	-	-	RSV Mille 2000 + "R"
12	Brake pipe fixing plate	-	-	-	-	RSV Mille 2000 + "R"
13	Screw w/ flange	M5x12*	-	-	-	RSV Mille 2000 + "R"
14	Rubber spacer	*	-	-	-	RSV Mille 2000 + "R"
15	Screw w/ flange	M6x25*	-	-	-	RSV Mille 2000 + "R"
16	Self-locking nut	M6*	-	-	-	RSV Mille 2000 + "R"
17	T bush	*	-	-	-	RSV Mille 2000 + "R"
18	Hose clamp	-	-	-	-	RSV Mille 2000 + "R"
19	Rubber pipe	-	-	-	-	RSV Mille 2000 + "R"
20	Screw w/ flange	M6x12*	-	-	-	RSV Mille 2000 + "R"
21	Brake light switch	-	-	-	-	RSV Mille 2000 + "R"




• cooling system

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	3-way union		-	-		RSV Mille 2000 + "R"
2	Aluminium washer		-	-		RSV Mille 2000 + "R"
3	Hose clamp		-	-		RSV Mille 2000 + "R"
4	Three-way manifold		-	-		RSV Mille 2000 + "R"
5	Hose clamp	17-25	-	-		RSV Mille 2000 + "R"
6	Water hose manifold/cooler		-	-		RSV Mille 2000 + "R"
7	Engine-manifold pipe		-	-		RSV Mille 2000 + "R"
8	Hose clip	D23,5x8*	-	-		RSV Mille 2000 + "R"
9	Thermostat-pump pipe		-	-		RSV Mille 2000 + "R"
10	Thermostat-cooler pipe		-	-		RSV Mille 2000 + "R"
11	Manifold breather pipe		-	-		RSV Mille 2000 + "R"
12	Manifold-union breather pipe		-	-		RSV Mille 2000 + "R"
13	Union-manifold breather pipe		-	-		RSV Mille 2000 + "R"
14	Hose clip		-	-		RSV Mille 2000 + "R"
15	Thermostat valve set	75°C	-	-		RSV Mille 2000 + "R"
16	Thermostat-engine pipe		-	-		RSV Mille 2000 + "R"
17	Thermal switch		-	-		RSV Mille 2000 + "R"




• water coolers

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION 1	COUNTRY	MODEL
1	Fascetta stringitubo		-	-	-	RSV Mille 2000 + "R"
2	Radiatore acqua dx grigio		-	-	-	RSV Mille 2000 + "R"
3	Radiatore acqua sx grigio		-	-	-	RSV Mille 2000 + "R"
4	Tubo acqua radiatori		-	-	-	RSV Mille 2000 + "R"
5	Ventola cpl.		-	-	-	RSV Mille 2000 + "R"
6	Rosetta	6,4x12*	-	-	-	RSV Mille 2000 + "R"
7	Vite TE flangiata	M6x20*	-	-	-	RSV Mille 2000 + "R"
8	Bussola a 'T'	*	-	-	-	RSV Mille 2000 + "R"
9	Gommino	*	-	-	-	RSV Mille 2000 + "R"
10	Vite TE flangiata	M6x12*	-	-	-	RSV Mille 2000 + "R"
11	Dado	M6*	-	-	-	RSV Mille 2000 + "R"
12	Silent-block	*	-	-	-	RSV Mille 2000 + "R"




• **expansion tank**

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION 1	COUNTRY	MODEL
1	Screw w/ flange	M5x16*	-	-	-	RSV Mille 2000 + "R"
2	Rubber w/ insert	*	-	-	-	RSV Mille 2000 + "R"
3	Hose clamp	D11,3	-	-	-	RSV Mille 2000 + "R"
4	Hose clamp	17-25	-	-	-	RSV Mille 2000 + "R"
5	Hose clip	D23,5x8*	-	-	-	RSV Mille 2000 + "R"
6	Frame ground bush	-	-	-	-	RSV Mille 2000 + "R"
7	Screw w/ flange	M6x16*	-	-	-	RSV Mille 2000 + "R"
8	Pump-Inlet pipe	-	-	-	-	RSV Mille 2000 + "R"
9	Screw w/ flange	M6x20*	-	-	-	RSV Mille 2000 + "R"
10	Oil plug gasket	-	-	-	-	RSV Mille 2000 + "R"
11	Fuel pipe	5,5x10	-	-	-	RSV Mille 2000 + "R"
12	Adhesive sponge	-	-	-	-	RSV Mille 2000 + "R"
13	Plug	-	-	-	-	RSV Mille 2000 + "R"
14	Expansion tank	-	-	-	-	RSV Mille 2000 + "R"
15	Filler cap	-	-	-	-	RSV Mille 2000 + "R"
16	Plug	-	-	-	-	RSV Mille 2000 + "R"




• oil tank

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Oil tank	STD	-	-		RSV Mille 2000 + "R"
1	Oil tank	R	-	-		RSV Mille 2000 + "R"
2	Oil filler cap	-	-	-		RSV Mille 2000 + "R"
3	Oil cooler, black	-	-	-		RSV Mille 2000 + "R"
4	Rubber spacer	*	-	-		RSV Mille 2000 + "R"
5	T bush	*	-	-		RSV Mille 2000 + "R"
6	Washer	10x14x1,6*	-	-		RSV Mille 2000 + "R"
7	Oil pipe screw	*	-	-		RSV Mille 2000 + "R"
8	Oil level pipe	-	-	-		RSV Mille 2000 + "R"
9	Washer	D8x16x1,5	-	-		RSV Mille 2000 + "R"
10	Screw w/ flange	M8x16*	-	-		RSV Mille 2000 + "R"
11	O-ring	3075	-	-		RSV Mille 2000 + "R"
12	Oil filter cpl.	-	-	-		RSV Mille 2000 + "R"
13	Oil pipe	6x12	-	-		RSV Mille 2000 + "R"
14	Oil pipe	-	-	-		RSV Mille 2000 + "R"
15	Screw w/ flange	M6x12*	-	-		RSV Mille 2000 + "R"
16	Screw w/ flange	M6x20*	-	-		RSV Mille 2000 + "R"
17	Hose clip	D11x6,6*	-	-		RSV Mille 2000 + "R"
18	White hose clip	D17,5x8	-	-		RSV Mille 2000 + "R"
19	Silent-block	-	-	-		RSV Mille 2000 + "R"
20	Hose clip	20x8	-	-		RSV Mille 2000 + "R"
21	Self-locking nut	M6*	-	-		RSV Mille 2000 + "R"
22	T bush	*	-	-		RSV Mille 2000 + "R"
23	Hex socket screw	M6x16*	-	-		RSV Mille 2000 + "R"
24	Hose clamp	-	-	-		RSV Mille 2000 + "R"
25	Washer	-	-	-		RSV Mille 2000 + "R"
26	Screw w/ flange	M6x16*	-	-		RSV Mille 2000 + "R"
27	O-ring	3056	-	-		RSV Mille 2000 + "R"
28	O-ring	115	-	-		RSV Mille 2000 + "R"
29	Oil pipe	-	-	-		RSV Mille 2000 + "R"
30	Oil pipe	-	-	-		RSV Mille 2000 + "R"
31	Oil pipe	12x19	-	-		RSV Mille 2000 + "R"




• air box

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION 1	COUNTRY	MODEL
1	Air filter		-	-		RSV Mille 2000 + "R"
2	Upper side filter case		-	-		RSV Mille 2000 + "R"
3	Lower side filter case		-	-	USA	RSV Mille 2000 + "R"
3	Lower side filter case		-	-	F	RSV Mille 2000 + "R"
3	Lower side filter case		-	-	I-A-AUS-B-CH-D-DK-E- GR-J-NL-P-UK	RSV Mille 2000 + "R"
4	O-ring	159	-	-		RSV Mille 2000 + "R"
5	Intake opening		-	-		RSV Mille 2000 + "R"
6	Gasket	D3	-	-		RSV Mille 2000 + "R"
7	Filter case front. supp.		-	-		RSV Mille 2000 + "R"
8	Reduction diaphragm		-	-	I-A-CH-DK-E-GR-J-NL- P-UK-D	RSV Mille 2000 + "R"
8	Reduction diaphragm		-	-	B-AUS-USA	RSV Mille 2000 + "R"
9	Plate		-	-		RSV Mille 2000 + "R"
10	Intake hose		-	-		RSV Mille 2000 + "R"
11	Hose clamp	D9,1*	-	-		RSV Mille 2000 + "R"
12	Hose clamp	100-120	-	-		RSV Mille 2000 + "R"
13	Hose clamp	D10,1*	-	-		RSV Mille 2000 + "R"
14	Fuel pipe	6x10	-	-		RSV Mille 2000 + "R"
15	Plug		-	-		RSV Mille 2000 + "R"
16	T bush	*	-	-		RSV Mille 2000 + "R"
17	Screw w/ flange	M6x12*	-	-		RSV Mille 2000 + "R"
18	Self-tapping screw	*	-	-		RSV Mille 2000 + "R"
19	Screw w/ flange	M5x16*	-	-		RSV Mille 2000 + "R"
20	Screw w/ flange	M6x16*	-	-		RSV Mille 2000 + "R"
21	Rubber spacer	*	-	-		RSV Mille 2000 + "R"
22	Spacer	*	-	-		RSV Mille 2000 + "R"
23	Hose clamp	d.15,8	-	-		RSV Mille 2000 + "R"
24	Oil breather pipe	9x14	-	-		RSV Mille 2000 + "R"
25	Intake hose gasket		-	-		RSV Mille 2000 + "R"




• fuel pump I

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION 1	COUNTRY	MODEL
1	Fuel pump flange		-	-	-	RSV Mille 2000 + "R"
2	Self-tapping screw	*	-	-	-	RSV Mille 2000 + "R"
3	Self-tapping screw	*	-	-	-	RSV Mille 2000 + "R"
4	Screw w/ flange	M5x16*	-	-	-	RSV Mille 2000 + "R"
5	Fuel pump rubber		-	-	-	RSV Mille 2000 + "R"
6	O-ring	199	-	-	-	RSV Mille 2000 + "R"
7	Fuel pipe pump-filter		-	-	-	RSV Mille 2000 + "R"
8	Fuel filter		-	-	-	RSV Mille 2000 + "R"
9	Fuel pump		-	-	-	RSV Mille 2000 + "R"
10	O-ring	3125	-	-	-	RSV Mille 2000 + "R"
11	Breather pipe	7,5x12,5	STD	-	-	RSV Mille 2000 + "R"
11	Breather plug		R	-	-	RSV Mille 2000 + "R"
12	Fuel pump support		-	-	-	RSV Mille 2000 + "R"
13	Level sensor		-	-	-	RSV Mille 2000 + "R"
14	Fuel pipe	7,5x14,5	-	-	-	RSV Mille 2000 + "R"
15	White hose clip	D17,5x8	-	-	-	RSV Mille 2000 + "R"
16	Hose clip	D12,5x8*	-	-	-	RSV Mille 2000 + "R"




• fuel pump II

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Bored screw		-	-		RSV Mille 2000 + "R"
2	Gasket	18x12,2x1,5	-	-		RSV Mille 2000 + "R"
3	Screw w/ flange	M6x16*	-	-		RSV Mille 2000 + "R"
4	Hose clamp	D10,1*	-	-		RSV Mille 2000 + "R"
5	Hose clip		-	-		RSV Mille 2000 + "R"
6	Washer	6,4x12*	-	-		RSV Mille 2000 + "R"
7	Screw w/ flange	M6x12*	-	-		RSV Mille 2000 + "R"
8	Tank breather pipe	STD	-	-		RSV Mille 2000 + "R"
8	Tank breather pipe	R	-	-		RSV Mille 2000 + "R"
9	Screw w/ flange	M5x12*	-	-		RSV Mille 2000 + "R"
10	Union		-	-		RSV Mille 2000 + "R"
11	2-way union		-	-		RSV Mille 2000 + "R"
12	Spacer	*	-	-		RSV Mille 2000 + "R"
13	Fuel pump wiring		-	-		RSV Mille 2000 + "R"
14	Screw w/ flange	M5x20*	-	-		RSV Mille 2000 + "R"
15	Fuel pipe	6x13	-	-		RSV Mille 2000 + "R"
16	Hose clip	D12,5x8*	-	-		RSV Mille 2000 + "R"
17	Fuel pipe		-	-		RSV Mille 2000 + "R"
18	Union		-	-		RSV Mille 2000 + "R"
19	O-ring	123	-	-		RSV Mille 2000 + "R"



• engine


REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Engine	990	-	-	USA	RSV Mille 2000 + "R"
1	Engine	990	-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
2	Sprocket cover, alum.180		-	-	-	RSV Mille 2000 + "R"
3	Gear lever		-	-	-	RSV Mille 2000 + "R"
4	Lever rubber		-	-	-	RSV Mille 2000 + "R"
5	Brake lever pin		-	-	-	RSV Mille 2000 + "R"
6	Circlip	d9	-	-	-	RSV Mille 2000 + "R"
7	Spacer	D6x8x13,5*	-	-	-	RSV Mille 2000 + "R"
8	Hex socket screw	M6x30*	-	-	-	RSV Mille 2000 + "R"
9	Hex socket screw	M6x20*	-	-	-	RSV Mille 2000 + "R"
10	Oil pipe	6x12	-	-	-	RSV Mille 2000 + "R"
11	"Y" union		-	-	-	RSV Mille 2000 + "R"
12	Hose clip	D11x6,6*	-	-	-	RSV Mille 2000 + "R"
13	Anti-return valve		-	-	-	RSV Mille 2000 + "R"



• exhaust pipe

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Exhaust pipes spring	-	-	-		RSV Mille 2000 + "R"
2	Exhaust pipe gasket	-	-	-		RSV Mille 2000 + "R"
3	Front. Exhaust pipe	-	-	-		RSV Mille 2000 + "R"
4	Rear exhaust pipe	-	-	-		RSV Mille 2000 + "R"
5	Central exhaust manifold	-	-	-		RSV Mille 2000 + "R"
6	Exhaust pipe	-	-	I-A-AUS-B-CH-DK-E- GR-J-NL-P-UK-F-D	USA	RSV Mille 2000 + "R"
6	Exhaust pipe	-	-			RSV Mille 2000 + "R"
7	Serpress nut	M8	-	-		RSV Mille 2000 + "R"
8	Hex socket screw	M8x50*	-	-		RSV Mille 2000 + "R"
9	Self-locking nut	M8*	-	-		RSV Mille 2000 + "R"
10	Silencer fixing bush	-	-	-		RSV Mille 2000 + "R"
11	Rubber exhaust	-	-	-		RSV Mille 2000 + "R"
12	Washer	8,5x24x2*	-	-		RSV Mille 2000 + "R"
13	Spacer	*	-	-		RSV Mille 2000 + "R"
14	CO intake screw	-	-	-		RSV Mille 2000 + "R"
15	Washer	10x14x1,6*	-	-		RSV Mille 2000 + "R"
16	Pin	-	-	USA	USA	RSV Mille 2000 + "R"
17	Screw w/ flange	M6x16*	-	-	USA	RSV Mille 2000 + "R"
18	Exhaust pipe support clamp		R	-		RSV Mille 2000 + "R"
19	Screw w/ flange	M8x30*	-	-		RSV Mille 2000 + "R"


RSV Mille version



• front wheel RSV mille version


REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Tubeless tyre valve	STD	-	-		RSV Mille 2000 + "R"
2	Front RH whe.ou.spacer	STD	-	-		RSV Mille 2000 + "R"
3	Screw w/ flange	M8x20*	STD	-		RSV Mille 2000 + "R"
4	Washer	25,2x36x1	STD	-		RSV Mille 2000 + "R"
5	Wheel spindle nut		STD	-		RSV Mille 2000 + "R"
6	Front wheel spindle		STD	-		RSV Mille 2000 + "R"
7	Front/rear tyre	120/65-17"	STD	-		RSV Mille 2000 + "R"
8	Front brake disc	d.320	STD	-		RSV Mille 2000 + "R"
9	Front wheel		STD	-		RSV Mille 2000 + "R"
10	Gasket ring	30x47x7	STD	-		RSV Mille 2000 + "R"
11	Bearing	6005-2rs1	STD	-		RSV Mille 2000 + "R"
12	Internal spacer		STD	-		RSV Mille 2000 + "R"
13	Circlip		STD	-		RSV Mille 2000 + "R"

RSV Mille "R" version




• front wheel RSV mille R version

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Tubeless tyre valve		R	-	-	RSV Mille 2000 + "R"
2	Front RH whe.ou.spacer		R	-	-	RSV Mille 2000 + "R"
3	Hex socket screw	m8x20	R	-	-	RSV Mille 2000 + "R"
4	Washer	25,2x36x1	R	-	-	RSV Mille 2000 + "R"
5	Wheel spindle nut		R	-	-	RSV Mille 2000 + "R"
6	Front wheel spindle		R	-	-	RSV Mille 2000 + "R"
7	Front/rear tyre	120/65-17"	R	-	-	RSV Mille 2000 + "R"
8	Front brake disc gold flange		R	-	-	RSV Mille 2000 + "R"
9	Front wheel		R	-	-	RSV Mille 2000 + "R"
10	Gasket ring	30x47x7	R	-	-	RSV Mille 2000 + "R"
11	Bearing	6005-2rs1	R	-	-	RSV Mille 2000 + "R"
12	Internal spacer		R	-	-	RSV Mille 2000 + "R"
13	Snap ring	d47	R	-	-	RSV Mille 2000 + "R"



• front brake caliper


REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	RH Front brake caliper, gold		-	-		RSV Mille 2000 + "R"
2	LH Front brake caliper, gold		-	-		RSV Mille 2000 + "R"
3	Pads pair		-	-		RSV Mille 2000 + "R"
4	Air bleed valve		-	-		RSV Mille 2000 + "R"
5	Bleed valve cap		-	-		RSV Mille 2000 + "R"
6	Pin+split pin		-	-		RSV Mille 2000 + "R"
7	Spring		-	-		RSV Mille 2000 + "R"
8	Split pin		-	-		RSV Mille 2000 + "R"
9	Front brake disc	d.320	STD	-		RSV Mille 2000 + "R"
9	Front brake disc gold flange		R	-		RSV Mille 2000 + "R"
10	Hex socket screw	m10x1,25	R	-		RSV Mille 2000 + "R"
10	Screw w/ flange	M10x1,25	STD	-		RSV Mille 2000 + "R"



RSV Mille version

• rear wheel RSV mille version


REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Chain cpl conn.link		-	-		RSV Mille 2000 + "R"
2	Chain ring	Z=42	-	-		RSV Mille 2000 + "R"
3	Rear wheel		-	-		RSV Mille 2000 + "R"
4	Rear wheel spring drive holder		-	-		RSV Mille 2000 + "R"
5	Rear tyre	180/55-17"	-	-		RSV Mille 2000 + "R"
6	Flexible coupling rubber		-	-		RSV Mille 2000 + "R"
7	Tubeless tyre valve		-	-		RSV Mille 2000 + "R"
8	Rear wheel spacer		-	-		RSV Mille 2000 + "R"
9	Spring drive fixing bush		-	-		RSV Mille 2000 + "R"
10	Low self-locking nut	M10*	-	-		RSV Mille 2000 + "R"
11	Crown holder cpl.		-	-		RSV Mille 2000 + "R"
12	Rear wheel spindle		-	-		RSV Mille 2000 + "R"
13	Wheel spindle nut	m25x1,5	-	-		RSV Mille 2000 + "R"
14	Washer	25,2x36x1	-	-		RSV Mille 2000 + "R"
15	Gasket ring	30x52x7	-	-		RSV Mille 2000 + "R"
16	Spacer		-	-		RSV Mille 2000 + "R"
17	Circlip		-	-		RSV Mille 2000 + "R"
18	Pin	10x20	-	-		RSV Mille 2000 + "R"
19	Bearing	6005-2rs1	-	-		RSV Mille 2000 + "R"
20	Hex socket screw	m10x30	-	-		RSV Mille 2000 + "R"
21	Gasket ring	38x52x7	-	-		RSV Mille 2000 + "R"
22	Inside circlip	d55	-	-		RSV Mille 2000 + "R"
23	Bearing	30x55x13	-	-		RSV Mille 2000 + "R"
24	Spring drive spacer		-	-		RSV Mille 2000 + "R"
25	Connecting link	DID	-	-		RSV Mille 2000 + "R"
	Connecting link	RK	-	-		RSV Mille 2000 + "R"



RSV Mille "R" version


• rear wheel RSV mille R version

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Chain cpl conn.link		-	-		RSV Mille 2000 + "R"
2	Chain ring	Z=42	-	-		RSV Mille 2000 + "R"
3	Rear wheel		-	-		RSV Mille 2000 + "R"
4	Connecting link	RK	-	-		RSV Mille 2000 + "R"
4	Connecting link	DID	-	-		RSV Mille 2000 + "R"
5	Rear tyre	180/55-17"	-	-		RSV Mille 2000 + "R"
6	Flexible coupling rubber		-	-		RSV Mille 2000 + "R"
7	Tubeless tyre valve		-	-		RSV Mille 2000 + "R"
8	Rear wheel spacer		-	-		RSV Mille 2000 + "R"
9	Spring drive fixing bush		-	-		RSV Mille 2000 + "R"
10	Low self-locking nut	M10*	-	-		RSV Mille 2000 + "R"
11	Crown holder cpl.		-	-		RSV Mille 2000 + "R"
12	Rear wheel spindle		-	-		RSV Mille 2000 + "R"
13	Wheel spindle nut	m25x1,5	-	-		RSV Mille 2000 + "R"
14	Washer	25,2x36x1	-	-		RSV Mille 2000 + "R"
15	Gasket ring	38x52x7	-	-		RSV Mille 2000 + "R"
16	Spacer		-	-		RSV Mille 2000 + "R"
17	Snap ring	d52	-	-		RSV Mille 2000 + "R"
18	Spring drive spacer		-	-		RSV Mille 2000 + "R"
19	Bearing	6005-2rs1	-	-		RSV Mille 2000 + "R"
20	Bearing	30x55x13	-	-		RSV Mille 2000 + "R"
21	Gasket ring	38x52x7	-	-		RSV Mille 2000 + "R"
22	Inside circlip	d55	-	-		RSV Mille 2000 + "R"



• rear brake pump

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Brake oil tank complete		-	-		RSV Mille 2000 + "R"
2	Tank cap		-	-		RSV Mille 2000 + "R"
3	Hose clamp		-	-		RSV Mille 2000 + "R"
4	Rear brake pipe		-	-		RSV Mille 2000 + "R"
5	Rear brake pump union		-	-		RSV Mille 2000 + "R"
6	Rubber bellows		-	-		RSV Mille 2000 + "R"
7	Rear brake pump		-	-		RSV Mille 2000 + "R"
8	Brake pump rod		-	-		RSV Mille 2000 + "R"
9	Fork		-	-		RSV Mille 2000 + "R"
10	O-ring	112	-	-		RSV Mille 2000 + "R"
11	Lever rubber		-	-		RSV Mille 2000 + "R"
12	Brake lever pin		-	-		RSV Mille 2000 + "R"
13	Rear brake lever pin		-	-		RSV Mille 2000 + "R"
14	Rear brake lever spring		-	-		RSV Mille 2000 + "R"
15	O-ring	114	-	-		RSV Mille 2000 + "R"
16	Washer	10,5x21x2*	-	-		RSV Mille 2000 + "R"
17	Nut	M6*	-	-		RSV Mille 2000 + "R"
18	Hex socket screw	M6x20*	-	-		RSV Mille 2000 + "R"
19	Circlip	d9	-	-		RSV Mille 2000 + "R"
20	Screw w/ flange	M5x16*	-	-		RSV Mille 2000 + "R"
21	Gear selector fork clips		-	-		RSV Mille 2000 + "R"
22	Screw w/ flange	M6x20*	-	-		RSV Mille 2000 + "R"
23	Rear brake lever		-	-		RSV Mille 2000 + "R"
24	Brake lever support		-	-		RSV Mille 2000 + "R"
25	Rear brake pump support		-	-		RSV Mille 2000 + "R"
26	Hex socket screw	M6x45*	-	-		RSV Mille 2000 + "R"
27	Hex socket screw	M8x50*	-	-		RSV Mille 2000 + "R"




• rear brake caliper

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION 1	COUNTRY	MODEL
1	Brake supp. plate pin		-	-		RSV Mille 2000 + "R"
2	Rear brake disc		-	-		RSV Mille 2000 + "R"
3	Speedometer sensor cpl.		-	-		RSV Mille 2000 + "R"
4	Copper washer		-	-		RSV Mille 2000 + "R"
5	Oil pipe screw	*	-	-		RSV Mille 2000 + "R"
6	Rear brake pipe		-	-		RSV Mille 2000 + "R"
7	Rear brake caliper		-	-		RSV Mille 2000 + "R"
8	Pads pair		-	-		RSV Mille 2000 + "R"
9	Pin+split pin		-	-		RSV Mille 2000 + "R"
10	Air bleed valve		-	-		RSV Mille 2000 + "R"
11	Bleed valve cap		-	-		RSV Mille 2000 + "R"
12	Screw w/ flange	M8x20*	-	-		RSV Mille 2000 + "R"
13	Screw w/ flange	M6x20*	-	-		RSV Mille 2000 + "R"
14	Rear brake pipe support		-	-		RSV Mille 2000 + "R"
15	Washer	5,5x15x1,6*	-	-		RSV Mille 2000 + "R"
16	Screw w/ flange	M5x12*	-	-		RSV Mille 2000 + "R"
17	Brake hanger plate		-	-		RSV Mille 2000 + "R"
18	Screw w/ flange	M8x20*	-	-		RSV Mille 2000 + "R"




10




• headlight

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Headlight		-	-	USA	RSV Mille 2000 + "R"
1	Headlight		-	-	I-A-B-CH-D-DK-E-F-GR-NL-P	RSV Mille 2000 + "R"
1	Headlight		-	-	AUS-J-UK	RSV Mille 2000 + "R"
2	Spring		-	-	-	RSV Mille 2000 + "R"
3	Self-tapping screw	*	-	-	-	RSV Mille 2000 + "R"
4	Washer	4,3x16*	-	-	-	RSV Mille 2000 + "R"
5	Lampholder		-	-	-	RSV Mille 2000 + "R"
6	Headlight wiring+boots		-	-	-	RSV Mille 2000 + "R"
7	Screw w/ flange	M6x16*	-	-	-	RSV Mille 2000 + "R"
8	Adjuster screw		-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
8	Adjuster screw		-	-	USA	RSV Mille 2000 + "R"
9	Adjuster screw		-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
9	Adjuster screw		-	-	USA	RSV Mille 2000 + "R"
10	Clip	M6*	-	-	-	RSV Mille 2000 + "R"




• turn indicators

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	RH front turn indicator		-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
1	RH front turn indicator		-	-	USA	RSV Mille 2000 + "R"
2	LH front turn indicator		-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
2	LH front turn indicator		-	-	USA	RSV Mille 2000 + "R"
3	Turn indicator lens		-	-	USA	RSV Mille 2000 + "R"
3	Turn indicator lens		-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
4	Screw	3,5x30	-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
4	Screw	2,9x32	-	-	USA	RSV Mille 2000 + "R"
5	Screw w/ flange	M6x16*	-	-	-	RSV Mille 2000 + "R"
6	Screw w/ flange	M6x20*	-	-	-	RSV Mille 2000 + "R"
7	Self-locking nut	M6*	-	-	-	RSV Mille 2000 + "R"




• taillight

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Taillight		-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
1	Taillight		-	-	USA	RSV Mille 2000 + "R"
2	Taillight lens		-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
2	Taillight lens		-	-	USA	RSV Mille 2000 + "R"
3	N.plate light window		-	-	-	RSV Mille 2000 + "R"
4	Rubber spacer		-	-	-	RSV Mille 2000 + "R"
5	Special screw	3,5x20	-	-	-	RSV Mille 2000 + "R"
6	Taillight wiring harn.		-	-	-	RSV Mille 2000 + "R"
7	Rubber spacer	*	-	-	-	RSV Mille 2000 + "R"
8	Washer	4,3x16*	-	-	-	RSV Mille 2000 + "R"
9	Self-tapping screw	*	-	-	-	RSV Mille 2000 + "R"




• front electrical system

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Spacer	6,5x10x19*	-	-	USA	RSV Mille 2000 + "R"
2	Diode		-	-	-	RSV Mille 2000 + "R"
3	Main wiring harness		-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
3	Main wiring harness		-	-	USA	RSV Mille 2000 + "R"
4	Horn		-	-	-	RSV Mille 2000 + "R"
5	Flasher unit		-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
5	Flasher unit	12V 10+10W	-	-	USA	RSV Mille 2000 + "R"
6	Fuses hook		-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
6	Fuses hook		-	-	USA	RSV Mille 2000 + "R"
7	Fuse holder box		-	-	-	RSV Mille 2000 + "R"
8	Fuse	15A	-	-	-	RSV Mille 2000 + "R"
9	Relay	12v/30a	-	-	-	RSV Mille 2000 + "R"
10	Self-tapping screw	*	-	-	-	RSV Mille 2000 + "R"
11	Relais support		-	-	-	RSV Mille 2000 + "R"
12	Screw w/ flange	M6x20*	-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
12	Screw w/ flange	M6x40*	-	-	USA	RSV Mille 2000 + "R"
13	Screw w/ flange	M8x16*	-	-	-	RSV Mille 2000 + "R"
14	Washer	6,4x12,5*	-	-	-	RSV Mille 2000 + "R"
15	Screw w/ flange	M6x25*	-	-	-	RSV Mille 2000 + "R"




• central electrical system

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Terminal cap		-	-		RSV Mille 2000 + "R"
2	HT coil		-	-		RSV Mille 2000 + "R"
3	Main wiring harness		-	-	USA	RSV Mille 2000 + "R"
3	Main wiring harness		-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
4	Ext.sparkplug cap		-	-		RSV Mille 2000 + "R"
5	Screw w/ flange	M6x12*	-	-		RSV Mille 2000 + "R"
6	Hex socket screw	M6x8*	-	-		RSV Mille 2000 + "R"
7	Voltage regulator		-	-		RSV Mille 2000 + "R"
8	Nut	M6*	-	-		RSV Mille 2000 + "R"




• rear electrical system

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Terminal cap		-	-		RSV Mille 2000 + "R"
2	Adhesive sponge		-	-		RSV Mille 2000 + "R"
3	Battery	12v-12ah	R	-		RSV Mille 2000 + "R"
3	Battery	12v-12ah	STD	-		RSV Mille 2000 + "R"
4	Battery fixing plate		R	-		RSV Mille 2000 + "R"
4	Battery fixing plate		STD	-		RSV Mille 2000 + "R"
5	Ground-battery lead		-	-		RSV Mille 2000 + "R"
6	Main wiring harness		-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
6	Main wiring harness		-	-	USA	RSV Mille 2000 + "R"
7	Screw w/ flange	M6x16*	-	-		RSV Mille 2000 + "R"
8	Inclination sensor		-	-		RSV Mille 2000 + "R"
9	Fuel tank rubber		-	-		RSV Mille 2000 + "R"
10	Gearcase prot.box		-	-		RSV Mille 2000 + "R"
11	Gearcase box cover		-	-		RSV Mille 2000 + "R"
12	Starter relay	12V/100A	-	-		RSV Mille 2000 + "R"
13	Relay	12V/20A	-	-		RSV Mille 2000 + "R"
14	Diode		-	-		RSV Mille 2000 + "R"
15	Relay-starter motor cable		-	-		RSV Mille 2000 + "R"
16	Nut	M6*	-	-		RSV Mille 2000 + "R"
17	Spring washer	6,4x11x0,5*	-	-		RSV Mille 2000 + "R"
18	Rubber spacer	*	-	-		RSV Mille 2000 + "R"
19	Battery support rubber		-	-		RSV Mille 2000 + "R"
20	Fuse	30a	-	-		RSV Mille 2000 + "R"
21	Rubber fuse box		-	-		RSV Mille 2000 + "R"
22	Rubber fuse box		-	-		RSV Mille 2000 + "R"
23	Positive pole cap		-	-		RSV Mille 2000 + "R"
24	Gearcase		-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
24	Gearcase		-	-	USA	RSV Mille 2000 + "R"
25	Washer	4,3x16*	-	-		RSV Mille 2000 + "R"
26	Rubber spacer	*	-	-		RSV Mille 2000 + "R"




• lock hardware kit

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Lock hardware kit	-	-	-	USA	RSV Mille 2000 + "R"
1	Lock hardware kit	-	-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
2	Saddle lock cpl.	-	-	-	-	RSV Mille 2000 + "R"
3	Fuel filler cap	-	-	-	-	RSV Mille 2000 + "R"
4	Main switch - steering lock	-	-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
4	Main switch - steering lock	-	-	-	USA	RSV Mille 2000 + "R"
5	Aprilia milled key	-	-	-	-	RSV Mille 2000 + "R"
6	Lock cable	-	-	-	-	RSV Mille 2000 + "R"
7	Pass.saddle connecting plate	-	-	-	-	RSV Mille 2000 + "R"
8	Shear rivet	M8x16*	-	-	-	RSV Mille 2000 + "R"
9	Screw w/ flange	M8x30*	-	-	-	RSV Mille 2000 + "R"
10	Screw w/ flange	M6x16*	-	-	-	RSV Mille 2000 + "R"
11	Hex socket screw	m6x35*	-	-	-	RSV Mille 2000 + "R"
12	Bush	-	-	-	-	RSV Mille 2000 + "R"
13	Hex socket screw	m5x30	-	-	-	RSV Mille 2000 + "R"
14	Hex socket screw	m5x16	-	-	-	RSV Mille 2000 + "R"
15	Upper cable-guide	-	-	-	-	RSV Mille 2000 + "R"
16	Bush	-	-	-	-	RSV Mille 2000 + "R"
17	Pass.saddle connecting plate	R	-	-	-	RSV Mille 2000 + "R"




• decal

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Technical decal set	-	rac		USA	RSV Mille 2000 + "R"
1	Technical decal set	-	black-blue-red-yell	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK		RSV Mille 2000 + "R"
1	Technical decal set	-	black-blue-red-yell		USA	RSV Mille 2000 + "R"
1	Technical decal set	-	rac	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK		RSV Mille 2000 + "R"
2	Front fairing decal set	-	black		-	RSV Mille 2000 + "R"
2	Front fairing decal set	-	red		-	RSV Mille 2000 + "R"
2	Front fairing decal set	-	blue		-	RSV Mille 2000 + "R"
2	Front fairing decal set	-	yell		-	RSV Mille 2000 + "R"
2	Front fairing decal set	-	rac		-	RSV Mille 2000 + "R"
3	Fairing decal set	-	blue		-	RSV Mille 2000 + "R"
3	Fairing decal set	-	yell		-	RSV Mille 2000 + "R"
3	Fairing decal set	-	red		-	RSV Mille 2000 + "R"
3	Fairing decal set	-	black		-	RSV Mille 2000 + "R"
3	Fairing decal set	-	rac		-	RSV Mille 2000 + "R"
4	Rear fairing decal set	-	black		-	RSV Mille 2000 + "R"
4	Rear fairing decal set	-	red		-	RSV Mille 2000 + "R"
4	Rear fairing decal set	-	blue		-	RSV Mille 2000 + "R"
4	Rear fairing decal set	-	yell		-	RSV Mille 2000 + "R"
4	Rear fairing decal set	-	rac		-	RSV Mille 2000 + "R"



• plate set and handbook

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Toolkit		-	-		RSV Mille 2000 + "R"
2	Operator's handbook-I-F-D-		-	-	I-B-D-F-A-CH	RSV Mille 2000 + "R"
2	Operator's handbook - AUS-		-	-	AUS	RSV Mille 2000 + "R"
2	Operator's handbook-gr-j-uk-		-	-	GR-J	RSV Mille 2000 + "R"
2	Operator's handbook-P-E-UK-		-	-	E-UK-P	RSV Mille 2000 + "R"
2	Operator's handbook-NL-DK-SF-		-	-	DK-NL	RSV Mille 2000 + "R"
2	Operator's handbook - USA-		-	-	USA	RSV Mille 2000 + "R"
3	Tamperproof dataplate		-	-	F	RSV Mille 2000 + "R"
3	Tamperproof dataplate		-	-	AUS	RSV Mille 2000 + "R"
4	CEE dataplate		-	-	I-A-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
5	ECE dataplate		-	-	I-A-B-CH-D-DK-E-F-GR-NL-P-UK	RSV Mille 2000 + "R"
5	ECE dataplate		-	-	J	RSV Mille 2000 + "R"
6	DGM dataplate	R	-	-	I-GR	RSV Mille 2000 + "R"
6	DGM dataplate	STD	-	-	I-GR	RSV Mille 2000 + "R"
7	Constructor dataplate		-	-	B	RSV Mille 2000 + "R"
7	Constructor dataplate		-	-	I-A-DK-E-GR-J-NL-P-UK-D	RSV Mille 2000 + "R"
7	Constructor dataplate		-	-	F	RSV Mille 2000 + "R"
7	Constructor dataplate		-	-	CH	RSV Mille 2000 + "R"
7	Constructor dataplate		-	-	AUS	RSV Mille 2000 + "R"
7	Constructor dataplate	R	-	-	USA	RSV Mille 2000 + "R"
7	Constructor dataplate	STD	-	-	USA	RSV Mille 2000 + "R"




• crankcases I

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Crankcase assy		-	-		RSV Mille 2000 + "R"
2	Pin	M8x12	-	-		RSV Mille 2000 + "R"
3	Pin	10x8	-	-		RSV Mille 2000 + "R"
4	Pin	M6x50	-	-		RSV Mille 2000 + "R"
5	Pin	m6x32	-	-		RSV Mille 2000 + "R"
6	Pin	m6x55	-	-		RSV Mille 2000 + "R"
7	Bushing half-shell, blue		-	-		RSV Mille 2000 + "R"
7	Bushing half-shell, yellow		-	-		RSV Mille 2000 + "R"
7	Bushing half-shell, red		-	-		RSV Mille 2000 + "R"
8	Bushing half-shell, blue		-	-		RSV Mille 2000 + "R"
8	Bushing half-shell, yellow		-	-		RSV Mille 2000 + "R"
8	Bushing half-shell, red		-	-		RSV Mille 2000 + "R"
9	Bushing half-shell, yellow		-	-		RSV Mille 2000 + "R"
9	Bushing half-shell, red		-	-		RSV Mille 2000 + "R"
9	Bushing half-shell, blue		-	-		RSV Mille 2000 + "R"
10	Pin	5x10	-	-		RSV Mille 2000 + "R"


B⁶ LOCTITE 243

D⁶ LOCTITE 574




• crankcases II

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Stud bolt	m10x171	-	-	-	RSV Mille 2000 + "R"
2	Hex socket screw	m6x20	-	-	-	RSV Mille 2000 + "R"
3	O-ring	59,52x2,62	-	-	-	RSV Mille 2000 + "R"
4	Oil filter cover		-	-	-	RSV Mille 2000 + "R"
5	Oil filter		-	-	-	RSV Mille 2000 + "R"
6	Contact screw	m10	-	-	-	RSV Mille 2000 + "R"
7	Magnetic drain plug	M12x1,5	-	-	-	RSV Mille 2000 + "R"
8	Gasket ring	6x10	-	-	-	RSV Mille 2000 + "R"
9	Hex socket screw	M6x10	-	-	-	RSV Mille 2000 + "R"
10	Jet	75	-	-	-	RSV Mille 2000 + "R"
11	Ball bearing	6206	-	-	-	RSV Mille 2000 + "R"
12	Short head screw	m6x13	-	-	-	RSV Mille 2000 + "R"
13	Ball bearing	6304	-	-	-	RSV Mille 2000 + "R"
14	Bearing	6003	-	-	-	RSV Mille 2000 + "R"
15	Hex socket screw	M6x80	-	-	-	RSV Mille 2000 + "R"
16	Hex socket screw	M6x25	-	-	-	RSV Mille 2000 + "R"
17	Angular bearing	3206	-	-	-	RSV Mille 2000 + "R"
18	Ball bearing	6205	-	-	-	RSV Mille 2000 + "R"
19	Ball bearing	16101	-	-	-	RSV Mille 2000 + "R"
20	Oil strainer		-	-	-	RSV Mille 2000 + "R"
21	Oil sprayer pipe		-	-	-	RSV Mille 2000 + "R"
22	Gasket		-	-	-	RSV Mille 2000 + "R"
23	Oil seal	40x47x7,5	-	-	-	RSV Mille 2000 + "R"
24	Oil seal	12x28x7	-	-	-	RSV Mille 2000 + "R"
25	Oil seal	11x22x7	-	-	-	RSV Mille 2000 + "R"
26	Chain guide		-	-	-	RSV Mille 2000 + "R"
27	Clutch disengagement flange		-	-	-	RSV Mille 2000 + "R"
28	Hex socket screw	M6x45	-	-	-	RSV Mille 2000 + "R"
29	Hex socket screw	m6x65	-	-	-	RSV Mille 2000 + "R"




• oil pump

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Oil pump shaft assy.	-	-	-	-	RSV Mille 2000 + "R"
2	Pin	4x15,8	-	-	-	RSV Mille 2000 + "R"
3	Internal and external rotor	-	-	-	-	RSV Mille 2000 + "R"
4	Pin	4x25,8	-	-	-	RSV Mille 2000 + "R"
5	Oil pressing pump casing	-	-	-	-	RSV Mille 2000 + "R"
6	Oil pump gear	z=42	-	-	-	RSV Mille 2000 + "R"
7	Internal and external rotor	-	-	-	-	RSV Mille 2000 + "R"
8	Oil pump cover cpl.	-	-	-	-	RSV Mille 2000 + "R"
9	Pressure adj. piston	-	-	-	-	RSV Mille 2000 + "R"
10	Spring	-	-	-	-	RSV Mille 2000 + "R"
11	Valve closer screw	m12x1,5	-	-	-	RSV Mille 2000 + "R"
12	Hex socket screw	M6x45	-	-	-	RSV Mille 2000 + "R"
13	Pin	-	-	-	-	RSV Mille 2000 + "R"
14	Oil pump gear	z=37	-	-	-	RSV Mille 2000 + "R"
15	Circlip	10x1	-	-	-	RSV Mille 2000 + "R"




• crankshaft I

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Crankcase assy.		-	-	-	RSV Mille 2000 + "R"
2	Connecting rod cpl.		-	-	-	RSV Mille 2000 + "R"
3	Hex socket screw	m10x20	-	-	-	RSV Mille 2000 + "R"
4	Connecting rod screw	m10x1	-	-	-	RSV Mille 2000 + "R"
5	Transmission key	4x5	-	-	-	RSV Mille 2000 + "R"
6	Transmission key	6x9	-	-	-	RSV Mille 2000 + "R"
7	Timing system gear cpl.		-	-	-	RSV Mille 2000 + "R"
8	Ext.wheel side counterweight		-	-	-	RSV Mille 2000 + "R"
9	Balance shaft gear cpl.		-	-	-	RSV Mille 2000 + "R"
10	Spring washer		-	-	-	RSV Mille 2000 + "R"
11	Primary drive gear		-	-	-	RSV Mille 2000 + "R"
12	Int.wheel side counterweight		-	-	-	RSV Mille 2000 + "R"
13	Spring washer		-	-	-	RSV Mille 2000 + "R"
14	Nut	m33x1,5	-	-	-	RSV Mille 2000 + "R"
15	Lower balance shaft		-	-	-	RSV Mille 2000 + "R"
16	Nut		-	-	-	RSV Mille 2000 + "R"
17	Washer	24x54x2	-	-	-	RSV Mille 2000 + "R"
18	Water pump gear	z=27	-	-	-	RSV Mille 2000 + "R"
19	Idle gear	z=28	-	-	-	RSV Mille 2000 + "R"
20	Pin	m6x32	-	-	-	RSV Mille 2000 + "R"
21	Clutch side counterweight		-	-	-	RSV Mille 2000 + "R"
22	Timing system gear cpl.		-	-	-	RSV Mille 2000 + "R"




• crankshaft II

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Crankcase assy.		-	-		RSV Mille 2000 + "R"
2	Piston assy	97 mm	-	-		RSV Mille 2000 + "R"
3	Piston ring set		-	-		RSV Mille 2000 + "R"
4	Cylinder with piston		-	-		RSV Mille 2000 + "R"
5	Piston pin	22x14x55	-	-		RSV Mille 2000 + "R"
6	Stop ring	22	-	-		RSV Mille 2000 + "R"
7	Cylinder base gasket		-	-		RSV Mille 2000 + "R"
8	Pin	5x10	-	-		RSV Mille 2000 + "R"
9	Chain tensioner assy.		-	-		RSV Mille 2000 + "R"
10	Plug		-	-		RSV Mille 2000 + "R"
11	Gasket ring	16x22	-	-		RSV Mille 2000 + "R"
12	Screw w/ flange	m8x45	-	-		RSV Mille 2000 + "R"




• valves cover

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Spacer screw cpl.	m6x23	-	-	-	RSV Mille 2000 + "R"
2	Valve cover gasket		-	-	-	RSV Mille 2000 + "R"
3	Rear valves cover		-	-	-	RSV Mille 2000 + "R"
4	Nut	M10	-	-	-	RSV Mille 2000 + "R"
5	Front valves cover		-	-	-	RSV Mille 2000 + "R"
6	Washer	8,4	-	-	-	RSV Mille 2000 + "R"
7	Hex socket screw	M8x25	-	-	-	RSV Mille 2000 + "R"
8	Hose clamp	65	-	-	-	RSV Mille 2000 + "R"
9	Intake flange		-	-	-	RSV Mille 2000 + "R"
10	Gasket ring	12x18	-	-	-	RSV Mille 2000 + "R"
11	Plate		-	-	-	RSV Mille 2000 + "R"
12	Temp. Sensor		-	-	-	RSV Mille 2000 + "R"
13	Hex socket screw	m6x100	-	-	-	RSV Mille 2000 + "R"
14	Stud bolt	m8x16x20	-	-	-	RSV Mille 2000 + "R"
15	Angular union		-	-	-	RSV Mille 2000 + "R"
16	Plug	m18x1,5	-	-	-	RSV Mille 2000 + "R"
17	Pipe		-	-	-	RSV Mille 2000 + "R"
18	Nut	m10	-	-	-	RSV Mille 2000 + "R"
19	Cylinder head gasket		-	-	-	RSV Mille 2000 + "R"
20	Hex socket screw	M10x40	-	-	-	RSV Mille 2000 + "R"




REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Front cylinder head cpl.		-	-		RSV Mille 2000 + "R"
2	Exhaust valve guide		-	-		RSV Mille 2000 + "R"
3	Intake valve guide		-	-		RSV Mille 2000 + "R"
4	Hex socket screw	M6x45	-	-		RSV Mille 2000 + "R"
5	Pin	6x8	-	-		RSV Mille 2000 + "R"
6	Hex socket screw	M6x30	-	-		RSV Mille 2000 + "R"
7	Washer	6,2x12x1	-	-		RSV Mille 2000 + "R"
8	Rear cylinder head cpl.		-	-		RSV Mille 2000 + "R"
9	Washer	6,1x9,8x1	-	-		RSV Mille 2000 + "R"
10	Hex socket screw	m6x55	-	-		RSV Mille 2000 + "R"
11	Self-tap screw	m5x12	-	-		RSV Mille 2000 + "R"
12	Camshaft sensor cpl.		-	-		RSV Mille 2000 + "R"
13	Hex socket screw	m6x55	-	-		RSV Mille 2000 + "R"
14	Washer	6,1x9,8x1	-	-		RSV Mille 2000 + "R"
15	Exhaust valve	31mm	-	-		RSV Mille 2000 + "R"
16	Intake valve	36 mm	-	-		RSV Mille 2000 + "R"
17	Valve spring plate		-	-		RSV Mille 2000 + "R"
18	Valve stem seal		-	-		RSV Mille 2000 + "R"
19	Ext. valve spring		-	-		RSV Mille 2000 + "R"
20	Int. valve spring		-	-		RSV Mille 2000 + "R"
21	Valve spring plate		-	-		RSV Mille 2000 + "R"
22	Valve half-cone		-	-		RSV Mille 2000 + "R"
23	Cable protection		-	-		RSV Mille 2000 + "R"
24	Valve lifter bucket		-	-		RSV Mille 2000 + "R"
25	Washer	6,2x12x1	-	-		RSV Mille 2000 + "R"
26	Hex socket screw	M6x30	-	-		RSV Mille 2000 + "R"




• pastiglie valvole

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Pad	2,925	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,7	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,675	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,75	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,775	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,8	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,825	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,85	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,9	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,95	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,975	-	-	-	RSV Mille 2000 + "R"
1	Pad	3,00	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,875	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,375	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,65	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,3	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,725	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,35	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,4	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,425	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,45	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,5	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,525	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,625	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,55	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,575	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,6	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,475	-	-	-	RSV Mille 2000 + "R"
1	Pad	2,325	-	-	-	RSV Mille 2000 + "R"



• valves pads

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Hex socket screw	m6x20	-	-		RSV Mille 2000 + "R"
2	Hex screw	M8x20	-	-		RSV Mille 2000 + "R"
3	Chain guide		-	-		RSV Mille 2000 + "R"
4	Bearings support Plate		-	-		RSV Mille 2000 + "R"
5	Chain guide		-	-		RSV Mille 2000 + "R"
6	Chain guide		-	-		RSV Mille 2000 + "R"
7	Washer	16,7x29x1	-	-		RSV Mille 2000 + "R"
8	Roller cage	16x22x10	-	-		RSV Mille 2000 + "R"
9	Timing system gear cpl.		-	-		RSV Mille 2000 + "R"
10	Spring washer	b8	-	-		RSV Mille 2000 + "R"
11	Hex screw	m8x45	-	-		RSV Mille 2000 + "R"
12	Exhaust camshaft		-	-		RSV Mille 2000 + "R"
13	Intake camshaft		-	-		RSV Mille 2000 + "R"
14	Timing system gear	z=29	-	-		RSV Mille 2000 + "R"
15	Timing system gear	z=29	-	-		RSV Mille 2000 + "R"
16	Hex socket screw	m6x11,5	-	-		RSV Mille 2000 + "R"
17	Bush	8,2x12x25	-	-		RSV Mille 2000 + "R"
18	Spacer screw	m6x16	-	-		RSV Mille 2000 + "R"
19	Camshaft chain		-	-		RSV Mille 2000 + "R"



• M MOLYKOTE G-N SLIDE PAST


• O ENGINE OIL

• B LOCTITE 243

• N MULTI PURPOSE GREASE BP L53

• front cylinder timing system


REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Upper balance shaft		-	-	-	RSV Mille 2000 + "R"
2	Ball bearing	16002	-	-	-	RSV Mille 2000 + "R"
3	Oil seal	15x24x5	-	-	-	RSV Mille 2000 + "R"
4	Bushing plate cpl.		-	-	-	RSV Mille 2000 + "R"
5	Chain guide		-	-	-	RSV Mille 2000 + "R"
6	Chain guide		-	-	-	RSV Mille 2000 + "R"
7	Hex screw	m6x20	-	-	-	RSV Mille 2000 + "R"
8	Washer	6,4	-	-	-	RSV Mille 2000 + "R"
9	Chain guide		-	-	-	RSV Mille 2000 + "R"
10	Hex screw	m6x35	-	-	-	RSV Mille 2000 + "R"
11	Washer	6,2x18x2	-	-	-	RSV Mille 2000 + "R"
12	Exhaust camshaft		-	-	-	RSV Mille 2000 + "R"
13	Intake camshaft		-	-	-	RSV Mille 2000 + "R"
14	Timing system gear	z=29	-	-	-	RSV Mille 2000 + "R"
15	Washer	16,7x29x1	-	-	-	RSV Mille 2000 + "R"
16	Hex socket screw	m6x11,5	-	-	-	RSV Mille 2000 + "R"
17	Transmission key	3x3,7	-	-	-	RSV Mille 2000 + "R"
18	Upper balance shaft gear cpl.		-	-	-	RSV Mille 2000 + "R"
19	Camshaft chain		-	-	-	RSV Mille 2000 + "R"
20	Counterweight		-	-	-	RSV Mille 2000 + "R"
21	Nut	m14	-	-	-	RSV Mille 2000 + "R"
22	Hex socket screw	m6x14	-	-	-	RSV Mille 2000 + "R"
23	Roller cage	16x22x10	-	-	-	RSV Mille 2000 + "R"
24	Timing system gear cpl.		-	-	-	RSV Mille 2000 + "R"
25	Roller cage plate		-	-	-	RSV Mille 2000 + "R"
26	Pin	10x8	-	-	-	RSV Mille 2000 + "R"
27	Bush	8,2x12x25	-	-	-	RSV Mille 2000 + "R"
28	Hex screw	m8x45	-	-	-	RSV Mille 2000 + "R"
29	Hex screw	m8x25	-	-	-	RSV Mille 2000 + "R"
30	Spring washer	b8	-	-	-	RSV Mille 2000 + "R"



*B LOCTITE 243

• gear box selector



REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Gear shaft+spring cpl.		-	-		RSV Mille 2000 + "R"
2	Fork shaft		-	-		RSV Mille 2000 + "R"
3	Fork		-	-		RSV Mille 2000 + "R"
4	Fork		-	-		RSV Mille 2000 + "R"
5	Fork		-	-		RSV Mille 2000 + "R"
6	Index washer		-	-		RSV Mille 2000 + "R"
7	Ball bearing	16101	-	-		RSV Mille 2000 + "R"
8	Shift cam		-	-		RSV Mille 2000 + "R"
9	Hex socket screw	m6x20	-	-		RSV Mille 2000 + "R"
10	Washer	6,4	-	-		RSV Mille 2000 + "R"
11	Washer		-	-		RSV Mille 2000 + "R"
12	Index assy. lever		-	-		RSV Mille 2000 + "R"
13	Index spring		-	-		RSV Mille 2000 + "R"
14	Pin	m6x55	-	-		RSV Mille 2000 + "R"
15	Spring		-	-		RSV Mille 2000 + "R"
16	Pin spring		-	-		RSV Mille 2000 + "R"
17	Bush		-	-		RSV Mille 2000 + "R"
18	Circlip		-	-		RSV Mille 2000 + "R"
19	Ball bearing	6304	-	-		RSV Mille 2000 + "R"
20	Washer	20,2x27,5	-	-		RSV Mille 2000 + "R"
21	Circlip	20x1,75	-	-		RSV Mille 2000 + "R"
22	Rubbered pinion	z=17	-	-	I-A-AUS-B-CH-D-DK-E-F-GR-J-NL-P-UK	RSV Mille 2000 + "R"
22	Rubbered pinion	z=16	-	-	USA	RSV Mille 2000 + "R"
23	Spring washer	34x16,3	-	-		RSV Mille 2000 + "R"
24	Washer		-	-		RSV Mille 2000 + "R"
25	Hex screw	m10x35	-	-		RSV Mille 2000 + "R"
26	Gear shaft+ratchet gear cpl.		-	-		RSV Mille 2000 + "R"
27	Washer		-	-		RSV Mille 2000 + "R"



*E LOCTITE ANTI-SEIZE 15378

• gear box


REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Primary gear shaft assy.	z=14	-	-	-	RSV Mille 2000 + "R"
2	2nd pinion gear	z=23	-	-	-	RSV Mille 2000 + "R"
3	Washer	29,2x33,5	-	-	-	RSV Mille 2000 + "R"
4	Circlip	28x2	-	-	-	RSV Mille 2000 + "R"
5	3rd-4th pinion gear	z=19/22	-	-	-	RSV Mille 2000 + "R"
6	Washer	25,35x34,5	-	-	-	RSV Mille 2000 + "R"
7	Roller cage	25x29x13	-	-	-	RSV Mille 2000 + "R"
8	6th pinion gear	z=27	-	-	-	RSV Mille 2000 + "R"
9	2nd pinion gear	z=16	-	-	-	RSV Mille 2000 + "R"
10	Driven shaft		-	-	-	RSV Mille 2000 + "R"
11	2nd wheel gear	z=28	-	-	-	RSV Mille 2000 + "R"
12	6th wheel gear	z=23	-	-	-	RSV Mille 2000 + "R"
13	4th wheel gear	z=24	-	-	-	RSV Mille 2000 + "R"
14	3rd wheel gear	z=26	-	-	-	RSV Mille 2000 + "R"
15	5th wheel gear	z=22	-	-	-	RSV Mille 2000 + "R"
16	Washer	25,3x33,5	-	-	-	RSV Mille 2000 + "R"
17	1st wheel gear	z=35	-	-	-	RSV Mille 2000 + "R"
18	Washer	20,5x37x1	-	-	-	RSV Mille 2000 + "R"
19	Gear box cpl.6 speed		-	-	-	RSV Mille 2000 + "R"



*C LOCTITE 648
*O ENGINE OIL


• clutch

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Washer	30,2x50	-	-	-	RSV Mille 2000 + "R"
2	Oil pump gear	z=42	-	-	-	RSV Mille 2000 + "R"
3	Clutch drum		-	-	-	RSV Mille 2000 + "R"
4	Primary drive gear		-	-	-	RSV Mille 2000 + "R"
5	Primary transm.		-	-	-	RSV Mille 2000 + "R"
6	Spring washer	68x52x1,2	-	-	-	RSV Mille 2000 + "R"
7	Washer	52x62x1	-	-	-	RSV Mille 2000 + "R"
8	Spring		-	-	-	RSV Mille 2000 + "R"
9	Bush		-	-	-	RSV Mille 2000 + "R"
10	Springholder plate		-	-	-	RSV Mille 2000 + "R"
11	Screw	M8x16	-	-	-	RSV Mille 2000 + "R"
12	Washer	25x44,4x5	-	-	-	RSV Mille 2000 + "R"
13	Clutch hub		-	-	-	RSV Mille 2000 + "R"
14	Spring washer	24,5x40	-	-	-	RSV Mille 2000 + "R"
15	Nut	m24x1,5	-	-	-	RSV Mille 2000 + "R"
16	Steel clutch discs 10 pc.		-	-	-	RSV Mille 2000 + "R"
17	Lined clutch discs 9 pc.		-	-	-	RSV Mille 2000 + "R"
18	Clutch shaft cpl.		-	-	-	RSV Mille 2000 + "R"
19	Springholder plate cpl.		-	-	-	RSV Mille 2000 + "R"
20	Ball bearing	16004	-	-	-	RSV Mille 2000 + "R"
21	Clutch spring		-	-	-	RSV Mille 2000 + "R"
22	Washer	d6,5	-	-	-	RSV Mille 2000 + "R"
23	Hex screw	m6x25	-	-	-	RSV Mille 2000 + "R"
24	Washer	12,2x32x2	-	-	-	RSV Mille 2000 + "R"
25	Support disc		-	-	-	RSV Mille 2000 + "R"
26	Diaphragm		-	-	-	RSV Mille 2000 + "R"
27	Pressure plate		-	-	-	RSV Mille 2000 + "R"
28	Nut	m12	-	-	-	RSV Mille 2000 + "R"




REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Pin	m6x32	-	-	-	RSV Mille 2000 + "R"
2	Idle gear	z=28	-	-	-	RSV Mille 2000 + "R"
3	Water pump gear	z=28	-	-	-	RSV Mille 2000 + "R"
4	Water pump shaft assy.		-	-	-	RSV Mille 2000 + "R"
5	Pin		-	-	-	RSV Mille 2000 + "R"
6	Washer	10,1x22x1	-	-	-	RSV Mille 2000 + "R"
7	Pin	M8x12	-	-	-	RSV Mille 2000 + "R"
8	Gasket		-	-	-	RSV Mille 2000 + "R"
9	Clutch cover		-	-	-	RSV Mille 2000 + "R"
10	Bearing half-shell	30x33x18	-	-	-	RSV Mille 2000 + "R"
10	Bushing half-shell, yellow		-	-	-	RSV Mille 2000 + "R"
10	Bushing half-shell, red		-	-	-	RSV Mille 2000 + "R"
11	Bearing half-shell	20x24x16	-	-	-	RSV Mille 2000 + "R"
12	Oil seal	10x25x5	-	-	-	RSV Mille 2000 + "R"
13	Sliding ring		-	-	-	RSV Mille 2000 + "R"
14	Hex socket screw	m6x35	-	-	-	RSV Mille 2000 + "R"
15	Hex socket screw	m8x55	-	-	-	RSV Mille 2000 + "R"
16	Hex socket screw	m8x65	-	-	-	RSV Mille 2000 + "R"
17	Gasket ring	8x13	-	-	-	RSV Mille 2000 + "R"
18	Impeller		-	-	-	RSV Mille 2000 + "R"
19	Water pump casing		-	-	-	RSV Mille 2000 + "R"
20	Gasket		-	-	-	RSV Mille 2000 + "R"
21	Hex socket screw	m6x55	-	-	-	RSV Mille 2000 + "R"
22	Hex socket screw	M6x25	-	-	-	RSV Mille 2000 + "R"
23	Gasket ring	6x10	-	-	-	RSV Mille 2000 + "R"
24	Diaphragm disc cpl.		-	-	-	RSV Mille 2000 + "R"
25	Hex socket screw	M5x20	-	-	-	RSV Mille 2000 + "R"
26	Oil pressure switch	m10x1	-	-	-	RSV Mille 2000 + "R"
27	Hex socket screw	m6x50	-	-	-	RSV Mille 2000 + "R"

- *B LOCTITE 243
- *C LOCTITE 648
- *M MOLYKOTE G-N SLIDE PASTE
- *N MULTI PORPOUSE GREASE BP L53
- *O ENGINE OIL
- *Q SILASTIC 732 RTV



• **ignition unit**

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION 1	COUNTRY	MODEL
1	Sprag clutch gear	z=64	-	-	-	RSV Mille 2000 + "R"
2	Ignition unit	12v 380w	-	-	-	RSV Mille 2000 + "R"
3	Sprag clutch		-	-	-	RSV Mille 2000 + "R"
4	Sprag clutch housing		-	-	-	RSV Mille 2000 + "R"
5	Hex socket screw	M8x16	-	-	-	RSV Mille 2000 + "R"
6	Hex socket screw	m16x30	-	-	-	RSV Mille 2000 + "R"
7	Washer	a17	-	-	-	RSV Mille 2000 + "R"
8	Ignition cover		-	-	-	RSV Mille 2000 + "R"
9	Plug	m24x1,5	-	-	-	RSV Mille 2000 + "R"
10	O-ring	23,3x2,4	-	-	-	RSV Mille 2000 + "R"
11	Hex socket screw	M6x40	-	-	-	RSV Mille 2000 + "R"
12	Screw w/ flange	m6x16	-	-	-	RSV Mille 2000 + "R"
13	Cable protection		-	-	-	RSV Mille 2000 + "R"
14	Gasket		-	-	-	RSV Mille 2000 + "R"
15	Hex socket screw	m6x35	-	-	-	RSV Mille 2000 + "R"
16	Pin	M6x50	-	-	-	RSV Mille 2000 + "R"
17	Idle gear	z=30	-	-	-	RSV Mille 2000 + "R"
18	Double gear	z=11/19	-	-	-	RSV Mille 2000 + "R"
19	Starter motor cpl.		-	-	-	RSV Mille 2000 + "R"
20	Starter motor revision kit		-	-	-	RSV Mille 2000 + "R"
21	O-ring	24,4x3,1	-	-	-	RSV Mille 2000 + "R"
22	Hex socket screw	m6x30	-	-	-	RSV Mille 2000 + "R"
23	Spark plug	12	-	-	-	RSV Mille 2000 + "R"
24	Int.sparkplug cap		-	-	-	RSV Mille 2000 + "R"
25	Ext.sparkplug cap		-	-	-	RSV Mille 2000 + "R"
26	HT coil		-	-	-	RSV Mille 2000 + "R"




• **throttle body**

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION_1	COUNTRY	MODEL
1	Throttle body cpl.	-	-	-	-	RSV Mille 2000 + "R"
2	Throttle body revision kit	-	-	-	-	RSV Mille 2000 + "R"
3	Sensor pipe	110mm	-	-	-	RSV Mille 2000 + "R"
4	Throttle cable supp.plate cpl.	-	-	-	-	RSV Mille 2000 + "R"
5	Throttle body sensor	-	-	-	-	RSV Mille 2000 + "R"
6	Injection valve cpl.	-	-	-	-	RSV Mille 2000 + "R"
7	Gasket set	-	-	-	-	RSV Mille 2000 + "R"
8	Fuel pressure regulator	-	-	-	-	RSV Mille 2000 + "R"
9	Sensor pipe	95mm	-	-	-	RSV Mille 2000 + "R"
10	3-way union	-	-	-	-	RSV Mille 2000 + "R"
11	Sensor pipe	30mm	-	-	-	RSV Mille 2000 + "R"
12	Pressure sensor	-	-	-	-	RSV Mille 2000 + "R"
13	O-ring	2018	-	-	-	RSV Mille 2000 + "R"
14	Spring	-	-	-	-	RSV Mille 2000 + "R"
15	Min.eng.spd adj.cable	-	-	-	-	RSV Mille 2000 + "R"
16	Cap	-	-	-	-	RSV Mille 2000 + "R"



ATTENTION:
For engine type 990 only this lubrication, adhesives and sealing compound are used

ATTENZIONE:
Per motori tipo 990 solo i lubrificanti, adesivi e sigillanti indicati sono usati



• sealing and lubricating agents

REF. TAV.	DESCR.	DETAIL	VERSION	VERSION 1	COUNTRY	MODEL
1	Loctite (blue)	243 10cc.	-	-	-	RSV Mille 2000 + "R"
2	Loctite (green)	648 5gr.	-	-	-	RSV Mille 2000 + "R"
3	Loctite (orange)	574	-	-	-	RSV Mille 2000 + "R"
4	Loctite Anti Seize	50ml.15378	-	-	-	RSV Mille 2000 + "R"
5	Loctite	8150	-	-	-	RSV Mille 2000 + "R"
6	Grease		-	-	-	RSV Mille 2000 + "R"
7	Motor oil		-	-	-	RSV Mille 2000 + "R"
8	Silastic 732 Rtv	100 gr.	-	-	-	RSV Mille 2000 + "R"
9	Gasket set		-	-	-	RSV Mille 2000 + "R"
10	Molykote	G-N 50gr.	-	-	-	RSV Mille 2000 + "R"